

# **GEOHM C**

## **Earth Tester**



3-349-089-03


17/5.21



## GEOHM C Measuring and Test Instrument

## GEOHM C Control and Display Unit





#### LCD after Switching the Instrument on

Please proceed as follows if the LCD display is not legible, i.e. too bright or too dark, after switching on the test instrument:

- 1 Simultaneously press the two right-hand keys to delete the memory which might be faulty.
- 2 Wait a few seconds to allow the display to be updated.
- 3 Readjust the contrast if necessary, see page 13.

Contents	Page
<b>1 Standard Equipment</b>	<b>5</b>
<b>2 Application</b>	<b>6</b>
2.1 Use for Intended Purpose	6
2.2 Use for Other than Intended Purpose	7
2.3 Liability and Guarantee	7
2.4 Opening of Equipment / Repair	7
2.5 Meanings of Symbols on the Instrument	7
2.6 Relevant Standards	7
<b>3 Safety Regulations</b>	<b>8</b>
<b>4 Terminology</b>	<b>9</b>
<b>5 Initial Start-Up</b>	<b>10</b>
5.1 Switching the Instrument On and Off	10
5.2 Battery Test	10
5.3 Battery / Rechargeable Battery Operation	10
5.4 Selecting Menus and Configuring Basic Settings	11
<b>6 Operation</b>	<b>15</b>
6.1 Display Functions	15
6.2 Online Help	15
6.3 Voltage Measurement	16
6.4 Earth Resistance Measurements in General	16
6.4.1 Configuring the Measuring Range – RANGE Function	17
6.4.2 Setting a Limit Value – LIMIT Function	18
6.5 Measuring Earthing Resistance	18
6.5.1 Measuring Circuit Setup, Measuring Instructions	18
6.6 Measuring Soil Resistivity	22
6.6.1 Geologic Surveys	22
6.6.2 Calculating Dissemination Resistance	23
6.7 Measuring Ohmic Resistance	24
6.7.1 2-Wire Connection	24
6.7.2 4-Wire Connection	24

Contents	Page
<b>7 Database Function</b>	<b>25</b>
7.1 Creating a Data Record – Data Function	25
7.2 Saving Measured Values to Memory – STORE Function	26
7.3 Querying Data Records – View Function	27
7.3.1 Deleting a Data Record from within a Memory Address – View Function	27
7.3.2 Deleting a Memory Address – Data Function	27
7.3.3 Delete All Memory Addresses – Data Function	28
<b>8 Characteristic Values</b>	<b>29</b>
<b>9 CE Declaration</b>	<b>30</b>
<b>10 Maintenance</b>	<b>30</b>
10.1 Housing	30
10.2 Fuses	30
10.3 Recalibration	31
<b>11 Device Return and Environmentally Compatible Disposal</b>	<b>31</b>
<b>12 Repair and Replacement Parts Service, Calibration Center and Rental Instrument Service</b>	<b>32</b>
<b>13 Product Support</b>	<b>32</b>

## 1 Standard Equipment

- 1 GEOHM C test instrument (M590A)
- 1 carrying strap
- 1 set of batteries
- 1 factory calibration certificate
- 1 set of operating instructions (this document)

### Optionally available accessories

Some measurements require accessories, e.g. earth electrodes. Furthermore, additional useful accessories are available.

Designation	Type	Article Number
Measuring accessories set for earth-resistance measurements in sturdy outdoor carrying bag with 2 earth spikes 420 mm long, 1 blue measurement cable 40 m long on cable reel with hand strap, 1 kV CAT III, 1 red measurement cable 20 m long on cable reel with hand strap, 1 kV CAT III, 1 black measurement cable 2 m long, 1 kV CAT IV, 1 green measurement cable 2 m long, 1 kV CAT IV, 1 red measurement cable 30 cm long, 1 kV CAT IV, 1 blue measurement cable 30 cm long, 1 kV CAT IV, 1 black test clamp with 4 mm socket, 1 green test clamp with 4 mm socket	E-SET BASIC	Z593A
Accessories for earthing measurement consisting of 1 x carrier bag, 4 earth spikes 500 mm, 1 x measuring cable 40 m blue on cable drum with hand strap, 1 x measuring cable 20 m red on cable drum with hand strap, 1 x measuring cable 5 m black, 1 x measuring cable 5 m green, 1 x test clamp with black 4 mm socket, 1 x test clamp with green 4 mm socket, 1 x hammer, 1 x roller tape measure, 1 x duster, 1 x writing pad with pen	E-SET PROFESSIONAL	Z592Z

Designation	Type	Article Number
Earth measurement case consisting of imitation leather case with 1 drum with 25 m measurement cable, 2 drums with 50 m measurement cable each, 3 measurement cables 0.5 m long, 1 measurement cable 2 m long, 1 test clamp, 4 earth drills, each 350 mm long, 1 dust cloth, 2 writing pads with forms	E-Set 5	Z590B
Earth Drill 420 mm for earth-resistance measurement	Earth Drill SP500	Z503Z
Cable reel for low-resistance and earth-resistance measurement, 25 m	TR25II	Z503X
Cable reel for low-resistance and earth-resistance measurement, 50 m	TR50II	Z503Y
Hard-shell case with compartment for one C series test instrument and accessories	HC30-C	Z541C
Hard-shell case with compartment for two C Series test instruments and accessories	HC40	Z541D

## 2 Application

### 2.1 Use for Intended Purpose

GEOHM C is a compact instrument for the testing of system earth electrodes and protective earth electrodes in mains systems in accordance with the following regulations:

DIN VDE 0100	Installation of power systems with nominal voltages of up to 1000 V
DIN VDE 0141	Earthing in AC systems with nominal voltages of greater than 1 kV
DIN VDE 0185	Lightning protection systems
DIN 18014	Foundation earth electrode - Planning, execution and documentation

The instrument is also capable of determining soil resistivity which is essential in calculating dimensions for earthing systems. It can thus be taken advantage of for simple geological surveys, and for the planning of earthing systems.

Beyond this, ohmic resistance can be measured at both solid and liquid conductors, and internal resistance can be measured at conductive components, as long as these are capacitance and induction-free.

The following quantities can be measured and tested with the GEOHM C:

- Voltage
- Frequency
- Earthing resistance
- Soil resistivity

If used for its intended purpose, safety of the operator and the instrument is assured.

### Correct Positioning of the Earth Electrode

Earth electrodes and earthing systems must always demonstrate the lowest possible overall resistance relative to the ground reference plane in order to assure safe operation of electrical systems, and to fulfill applicable regulations.

This resistance value is influenced by the soil resistivity of the surrounding soil, which depends upon the type of soil, how wet the soil is and the time of year.

Before the location of an earth electrode or an earthing system is finally established, it is advisable to examine prevailing soil characteristics. Soil resistivity can be measured at various depths in different soil layers with the earth tester. The results indicate, for example, whether or not it would be more favorable to drive the earth electrodes deep into the soil, i.e. to use long earth electrodes, or if additional electrodes may be necessary. Beyond this, different types of earth electrodes are available, for example earth strips, earth rods, mesh earth electrodes and earth plates, each with varying dissipation resistance values (see chapter 6.6.2 on page 23). The earth electrode with the most favorable geometry is selected depending upon soil characteristics.

### Earthing System Maintenance

Previously installed earth electrodes and earthing systems can be tested to determine whether or not their resistance values exceed allowable limits, and if so whether ageing of the system and/or changing soil characteristics have contributed to this situation.

### Measuring Method and Functional Principle

Earthing resistance is measured with the GEOHM C by means of the ammeter-voltmeter test method.

The battery powered, potential-free constant power source (quartz-controlled square-wave generator) delivers constant current of up to 10 mA at a frequency of 128 Hz to the measuring ranges.

In the interest of safety, maximum test voltage at the terminals is limited to 50 V with reference to earth.

Constant test current travels via terminal **E** through the earth electrode whose resistance  $R_E$  is to be measured, through the auxiliary resistor  $R_H$  and finally to terminal **H**.

The voltage drop which occurs due to earthing resistance  $R_E$ , and which is measured at terminals **ES** or **E** and **S**, is first fed first to an electronic filter

which is synchronous to the generator, and then to a synchronously controlled rectifier in order to eliminate influences caused by polarization voltages and stray alternating currents which are present in the soil to the greatest possible extent.

The earthing resistance to be measured is proportional to the voltage drop. It is displayed directly at the LCD in digital format.

Crucial operating conditions are continuously monitored for possible errors. The presence of interference voltage and values in excess of allowable auxiliary earth conductor resistance at the external current circuit are signaled by means of LEDs. Probe resistance at the voltage circuit is measured each time a measurement is started. If the allowable value is exceeded, the appropriate LED lights up.

Excessively low battery voltage and over-ranging are indicated at the LCD.

## 2.2 Use for Other than Intended Purpose

Using the instrument for any purposes other than those described in these instrument's operating instructions is contrary to use for intended purpose.

## 2.3 Liability and Guarantee

Gossen Metrawatt GmbH assumes no liability for property damage, personal injury or consequential damage resulting from improper or incorrect use of the product, in particular due to failure to observe the product documentation. Furthermore, all guarantee claims are rendered null and void in such cases.

Nor does Gossen Metrawatt GmbH accept any liability for data loss.

## 2.4 Opening of Equipment / Repair

The equipment may be opened only by authorized service personnel to ensure the safe and correct operation of the equipment and to keep the warranty valid.

Even original spare parts may be installed only by authorized service personnel.

In case the equipment was opened by unauthorized personnel, no warranty regarding personal safety, measurement accuracy, conformity with applicable safety measures or any consequential damage is granted by the manufacturer.

## 2.5 Meanings of Symbols on the Instrument



Indicates EU conformity



Protection class II device



Warning concerning a point of danger  
(Attention: observe documentation!)



9 V DC charging socket  
for NA102 charging adapter (article no. Z501N<sup>1)</sup>)



Measuring category 250 V CAT II device



This device may not be disposed of with the trash. Further information regarding the WEEE mark can be accessed on the Internet at [www.gossenmetrawatt.com](http://www.gossenmetrawatt.com) by entering the search term 'WEEE'.

## 2.6 Relevant Standards

The instrument has been manufactured and tested in compliance with the following safety regulations:

DIN EN 61 010-1/ VDE 0411-1	Safety requirements for electrical equipment for measurement, control and laboratory use – General requirements
DIN EN 61140 VDE 0140-1	Protection against electric shock Common aspects for installation and equipment
DIN EN 61326-1 VDE 0843-20-1	Electrical equipment for measurement, control and laboratory use – EMC requirements – Part 1: General requirements
IEC 61557/ EN 61557/ VDE 0413	Equipment for testing, measuring and monitoring of protective measures Part 1: General requirements Part 5: Resistance to earth

<sup>1)</sup> Battery charger NA102 Z501N is not included in the standard equipment and is no longer available as an optional accessory.

### 3 Safety Regulations

Observe this documentation, in particular all included safety information, in order to protect yourself and others from injury, and to prevent damage to the instrument.

- Carefully and completely read and adhere to these operating instructions.  
The document can be found at <http://www.gossenmetrawatt.com>. Retain this document for future reference.
- Tests/measurements may only be performed by a qualified electrician, or under the supervision and direction of a qualified electrician. The user must be instructed by a qualified electrician concerning performance and evaluation of the tests/measurements.
- Observe and comply with all safety regulations which are applicable for your work environment.
- Wear suitable and appropriate personal protective equipment (PPE) whenever working with the instrument.
- Use only the specified accessories (included in delivery or listed as optional) with the instrument.
- Carefully and completely read and adhere to the product documentation of the optional accessories. Retain these documents for future reference.
- The instrument may only be used as long as it's in good working order.  
Inspect the instrument before use. Pay particular attention to damage, broken insulation or kinked cables.
- Accessories and cables may only be used as long as they're fully intact.  
Inspect all cables and accessories before use. Pay particular attention to damage, broken insulation or kinked cables.
- If the instrument or an accessory doesn't function flawlessly, remove it from operation and secure it against inadvertent use.
- If the instrument or accessory is damaged during use, e.g. through falling, remove it from operation and secure it against inadvertent use.
- Do not use the instrument after long periods of storage under unfavorable conditions (e.g. humidity, dust or extreme temperature).
- Do not use the instrument after extraordinary stressing due to transport.

- The instrument must not be exposed to direct sunlight.
- Only use the instrument and the accessories in compliance with the specified technical data and under the specified conditions (ambient conditions, IP protection class, measuring category, etc.).
- The instrument and the included accessories may only be used for the tests/measurements described in the instrument's documentation.
- On account of the maximum test voltage of 50 V the test instrument may not be used in agricultural establishments.
- Do not use the instrument while the internal batteries are being charged.
- Do not use the instrument if the battery compartment cover has been removed.  
Otherwise you risk touching dangerous voltages.
- Rechargeable batteries must only be charged if they are fully intact. Inspect the batteries before use. Pay particular attention to leaking and damage.
- The instrument is equipped with fuses. The instrument may only be used as long as the fuses are in flawless condition. A defective fuse must be replaced.
- Fully unreel the cable before starting a test/measurement. Never perform a test/measurement with the cable rolled up.
- Upload your measurement data always manually from the test instrument to avoid data loss.

## 4 Terminology

In order to assure that the terminology used in these operating instructions is not misunderstood, the most important terms are defined below.

**Earth:** a term used as a designation for the planet Earth, as well as a connection to ground.

**Ground reference plane:** the zone in the ground within which no significant voltages occur between any two points as a result of earth current, especially the surface of the earth located outside of the sphere of influence of an earth electrode or earthing system (see also Figure 1 on page 9).

**Earth electrode:** a conductor which is embedded in, and electrically connected to ground, or a conductor which is embedded in concrete which has a large surface area in contact with the ground (e.g. a foundation)

**Earth cable:** a cable which is used to connect the system component to be grounded to an earth electrode, and which is laid above ground, or underground if insulated.

**Earthing system:** a system of electrically connected earth electrodes which is restricted to a specific local area, or other metal objects which have the same function (e.g. tower footings, armoring, metal cable jacketing and earthing blades).

**Ground (verb):** to connect an electrically conductive object to earth via an earthing system

**Earthing:** all means and measures in their entirety, which are required to ground an object

**Earthing resistance  $R_E$ :** resistance between the earthing system and the ground reference plane

**Soil resistivity  $\rho_E$ :** the specific electrical resistance of the soil. Usually defined as  $\Omega\text{m}^2$ :  $m = \Omega\text{m}$ , soil resistivity represents the resistance of a cube of earth along an edge with a length of 1 meter between two opposing surfaces of the cube.

**Dissipation resistance  $R_A$ :** earth resistance between the earth electrode and the ground reference plane. For all intense purposes  $R_A$  is an equivalent resistance (same as  $R_E$ ).

**Earth potential  $U_E$ :** voltage which occurs between the earthing system and the ground reference plane (see also Figure 1 on page 9)

**Contact voltage  $U_B$ :** the portion of earth potential which can be short-circuited by human being (see also Figure 1 on page 9), where the current path over the human body runs from hand to foot (horizontal distance of approximately 1 meter from the accessible part), or from hand to hand.





Figure 1 Ground-to-electrode potential and voltages with current carrying earth conductor

**Step voltage  $U_S$ :** the portion of earth potential which can be short-circuited by human being over a single step of 1 meter, where the current path over the human body runs from foot to foot (see also Figure 1 on page 9). No allowable limit values have been established for step voltage.

## 5 Initial Start-Up

### 5.1 Switching the Instrument On and Off



The instrument can be switched on by pressing any key.

The instrument is switched off manually by simultaneously pressing and holding the two outermost softkeys.

### 5.2 Battery Test

Five battery symbols ranging from depleted to fully charged continuously indicate the current battery level in the main menu.

### 5.3 Battery / Rechargeable Battery Operation

Four 1.5 V baby cells in accordance with IEC LR14 are required for operation of the GEOHM C. Rechargeable NiCd or NiMH batteries may be used as well.

For initial start-up or when only one solid segment remains in the battery symbol, the batteries must be replaced, or recharged if rechargeable batteries are used.

Check the batteries at short, regular intervals or after lengthy periods of storage to make sure no leakage has occurred. Leaking (rechargeable) batteries may no longer be used.



#### Note

Prior to lengthy periods of rest (e. g. holiday), we recommend removing the (rechargeable) batteries. This helps to prevent excessive depletion or leakage of batteries, which, under unfavourable circumstances, may cause damage to the instrument.

### Replacing (Rechargeable) Batteries

Only insert batteries or rechargeable batteries which are specified in chapter 8 on page 29. Do not mix batteries with rechargeable batteries and always replace a complete set of batteries or rechargeable batteries.



#### Attention!

Make sure that the instrument is completely disconnected from all external electrical circuits before opening the bottom of the housing!

- Loosen the two slotted screws at the battery compartment cover on the housing rear panel and remove the cover.
- Insert the new set of (rechargeable) batteries making certain they are poled in accordance with the symbols. Insert the two batteries which are half covered by the housing first.
- Replace the cover and retighten the screws.



#### Attention!

The instrument may not be operated if the battery compartment cover has not been installed and properly tightened!

- Dispose of batteries in an environmentally sound fashion, see chapter 10.2 on page 30.

### Charging Process (Rechargeable Batteries)

Charge your rechargeable batteries in an external battery charger.

The battery charger NA102 Z501N described in these operating instructions is no longer available.

Battery chargers NA102 Z501N, which are still available, may be used for charging rechargeable batteries in the test instrument as described below.



**Attention!**

Any other battery chargers may not be used at the instrument!



**Attention!**



Before connecting the battery charger to the charging socket at the instrument, make sure of the following points:

- **Rechargeable batteries have been installed (not normal batteries).**
- The instrument has been disconnected from the measuring circuit at all poles.
- The voltage selector at the charger has been set to 9 V.

- ◊ Connect the Z501N battery charger to the charging socket with the 3.5 mm jack plug.
- ◊ Set the voltage selector switch at the Z501N to 9 V.
- ◊ Switch the test instrument on. The test instrument recognizes the fact that a battery charger has been connected and starts the charging cycle. The segments of the battery symbol are continuously displayed in a sweeping pattern from left to right for the entire duration of the charging cycle.


Depleted batteries require a charging cycle of approximately 14 hours. If the batteries are exhausted to a great enough extent, the test instrument can no longer be switched on. If this is the case, leave the test instrument connected to the activated battery charger for about 30 minutes, and then proceed as described above.

**5.4 Selecting Menus and Configuring Basic Settings**



Press the ◀ or the ▶ key in order to display the desired measuring function, the desired device settings or the database functions.


## Setting the Clock



- ◇ Activate the Time key.
- ◇ The cursor appears at the first digit in the date. Enter the desired numeral with one of the softkeys. Numerals which do not appear can be displayed with the help of the **←** or the **→** key. Each time a numeral is selected, the cursor moves to the next position to the right.
- ◇ Date and time are saved as soon as the last numeral has been entered.
- ◇ The setup mode is exited by pressing the **START** key and the new settings become effective.


## Default Settings – Last Used Settings

A selection can be made here as to whether the menus will be displayed according to the default settings, or if the last opened menus should be displayed.




- ◇ Press the Setup key.
  - ◇ Press the Default key if necessary:
- on** ✓ Settings such as  $T_{on}$  (20 sec.) are reset to the default settings when the instrument is switched on.
- off** ✓ The last used settings remain effective when the instrument is switched on.
- ◇ Exit the setup menu by pressing the **←** key.

## Setting On-Time, Manual Shutdown




- ◇ Press the Setup key.
- ◇ Press the  $T_{on}$  key and then the 10sec, 20sec, 30sec or 60sec key depending upon the desired duration after which the test instrument should switch off automatically. Additional setting options can be displayed by activating the scroll bar with the  $\leftarrow$  or the  $\rightarrow$  key. If the “>>>>” setting is selected, no automatic shutdown occurs. The selected setting has a substantial influence on battery service life.
- ◇ Exit the setup menu by pressing the  $\leftarrow$  key.

## Background Illumination and Contrast



- ◇ Press the Display key.
  - ◇ In order to extend battery service life, display illumination can be switched off entirely. Press the corresponding softkey to this end.
- If LCD illumination is activated (ON), it is automatically switched off several seconds after the last key has been activated in order to extend battery service life. As soon as a key is activated again, illumination is switched back on.
- ◇ Contrast can be optimized with the two keys at the far right.
  - ◇ The setup menu is exited by pressing the **START** key, and the selected settings become effective.

## Self-Test



- The self-test is started from the main menu with the Test key. The test has a duration of several minutes.

The following information is displayed in the two headers:

**Type/Cal:** Device type / date of last calibration (balancing)

**Version:** Software version and issue date

Self-tests for items Chksum through LED are performed automatically, one after the other, and are checked off or marked with a horizontal dash if they are not passed.

**Chksum1/2:** Status display for internal testing (each test must be completed with a check mark). If not, the measuring and test instrument may no longer be used. Please contact our service center in this case.

**Relays:** Each relay is switched twice.

**LED:** The RH/RS and LIMIT LEDs each blink twice in red, and the Netz/Mains LED blinks twice in green and twice in red. The  $U_{noise}$  lamp blinks twice in red.

As soon as the tests in the left-hand column have been completed, the following tests must be started manually.

- **Illum:** Press the Test key twice in order to activate and deactivate display illumination.

- **Display:** Press the Test key after each test pattern has been displayed in order to test the display elements.
- **Keytest:** Perform the key test by pressing each of the softkeys once, and by pressing the start key once in each of its three positions. The keys appear filled in at the key pictograph after they have been tested.

Individual tests can be skipped by pressing the skip key before starting the respective test. These tests are then identified with a horizontal dash, as is also the case for tests which have not been passed.

## 6 Operation

### 6.1 Display Functions

The following items are displayed at the LCD:

- Measured values with abbreviated designations and units of measure
- The selected function
- Error messages

During measuring sequences which are executed automatically, measured values are saved and displayed in digital format until the next measuring sequence is started, or until the instrument is shut down automatically.

If the upper measuring range limit is exceeded, the upper limit appears in the display preceded by the ">" symbol (greater than) in order to indicate over-ranging.



#### Attention!

Earthing resistance measurements are not valid if any of the following displays indicate the occurrence of an error before or during measurement, or if low battery voltage is indicated.


### LED Functions

LED lights up red	Measuring Function	Significance	Remedy
$U_{Stör}/U_{noise}$	Interference voltage	Interference voltage in the soil to be measured exceeds the maximum value which can be compensated for by the earth tester.	Wait until the interference voltage clears on its own, or insert the test spike at a different location.
Netz/Mains	Voltage	Line voltage is present.	
LIMIT	Earthing resistance	$R_E$ is greater than the selected limit value.	Check the limit value, improve earthing.
$R_S > \max$	Probe resistance during power-up	Resistance exceeded at the external current circuit. Cause: open circuit, poor connection between test cable and auxiliary earth electrode or high resistance in the ground in proximity to the auxiliary earth electrode	<ul style="list-style-type: none"> <li>– Reposition the spike</li> <li>– Moisten the soil around the auxiliary earth electrode</li> <li>– Use an auxiliary spike</li> </ul>
$R_H > \max$	Auxiliary earth electrode resistance		


### 6.2 Online Help

Appropriate online help texts can be displayed at the LCD for each of the basic functions and sub-functions, **after the respective function has been selected in the corresponding menu.**

- ⇒ Press the **(i)** key to query online help.  
Press any key to exit the help function.




### 6.3 Voltage Measurement



#### Attention!

During voltage measurement no device may be connected to jacks E and H (or C1 and C2, respectively).

Voltage measurement between the **S** and **ES** jacks is started automatically as soon as the voltage measuring function has been selected. Switch-over between AC and DC is performed automatically. The same applies to the polarity indication for direct voltage.




- ⇨ Press the key in order to return to the main menu.

### 6.4 Earth Resistance Measurements in General

Perform measurements as follows after setting up the measuring circuit as described in the following sections:

- ⇨ In order to select the desired measurement type, press the **R<sub>E3-P</sub>** key for 3-pole, or the **R<sub>E4-P</sub>** key for 4-pole earth resistance measurement in accordance with the measuring circuit setup.



- ⇨ Press the **START** key in order to start the measurement.
- ⇨ Read the measured value.
- ⇨ Check to see whether or not any errors have been indicated by means of the display functions described above.
- ⇨ Eliminate any indicated errors and start the measurement again.

## 6.4.1 Configuring the Measuring Range – RANGE Function

### Automatic Measuring Range Selection

If automatic measuring range selection is used, the instrument selects the highest possible current it is capable of transmitting from the earth electrode to the auxiliary earth electrode. This is a constant current with a square-wave frequency of 128 Hz. The following current values and resistance measuring values are possible:

Constant Current	Resistance Measuring Range
10 mA	0.01 ... 19.99 $\Omega$
1 mA	0.1 ... 199.9 $\Omega$
100 $\mu$ A	1 $\Omega$ ... 1.999 k $\Omega$
100 $\mu$ A	10 $\Omega$ ... 19.99 k $\Omega$




#### Note

If a resolution of only 1  $\Omega$  occurs with an earthing resistance value of, for example, 1  $\Omega$ , resistance between the earth electrode and the auxiliary earth electrode is so great that a measuring current of only 100  $\mu$ A is possible. Remedy: Drive the auxiliary earth electrode deeper into the ground or pour a bucket of saltwater over the auxiliary earth electrode (only effective if the soil is dry). The auxiliary earth electrode becomes less resistive as a result and is capable of conducting a larger test current. Probe resistance is less critical, although a bucket of water may also be helpful if the soil is dry. Earthing resistance is not influenced by these measures. However, the earth electrode may not be artificially watered, because this would simulate optimized conditions for the measurement.

### Manual Measuring Range Selection

As a rule, you will not need to use manual measuring range selection unless no measurement value is displayed, or if greatly fluctuating measurement values occur with automatic range selection. In extreme cases, superimposed interference voltages may make it impossible for the automatic range selection function to find a suitable measuring range, and may result in continuous error messages. A suitable measuring range can be selected manually in such cases. However, extreme fluctuations in earthing resistance can only be eliminated by moving the measuring point to a different location.



- Press the RANGE key.
- Select a suitable measuring range.
- Start the measurement as described above.



#### Note

When the measuring range is selected manually, it must be kept in mind that the specified accuracy values are only valid as of measured values of at least 5% of the upper range limit (except in the 10  $\Omega$  range: separate specification for small values).


The measuring range can be set as high as 50 k $\Omega$  by means of manual measuring range selection.

## 6.4.2 Setting a Limit Value – LIMIT Function

If required, an earthing resistance limit value  $R_E$  can be selected by pressing the LIMIT key. If measured values in excess of this limit value occur, the red LIMIT LED lights up.

Activate the limit value menu.

Set the limit value.



### Setting the Limit Value:

Display the desired numeric value and a decimal point if required with the help of the ← and the → keys, and select the value with the corresponding softkey. The cursor moves one place to the right after each selection has been made. After entries have been made for a maximum of 3 places, and after either Ω or kΩ has been selected, the entry window is exited automatically. The cursor can be moved one place to the right or the entry window can be exited during data entry by pressing the → softkey. The selected limit value is automatically saved to memory when the entry window is exited.

## 6.5 Measuring Earthing Resistance



### Note

We recommend using measuring accessories sets for earth resistance measurements which are listed as optional accessories (see chapter 1 on page 5).

## 6.5.1 Measuring Circuit Setup, Measuring Instructions

### 3-Wire Connection




Figure 2 Measuring Earthing Resistance with a 3-Wire Test Setup

- Position the probe at least 20 meters, and the auxiliary earth electrode at least 40 meters from the earth electrode (see also Figure 2 on page 18).
- Make sure that contact resistance between the probe and the soil is not too great.
- If a 3-wire test setup is utilized, the earth electrode is connected to jack "E" at the test instrument with a measurement cable, the probe is connected to jack "S" and the auxiliary earth electrode is connected to jack "H".
- Press the  $R_{E3-P}$  key in order to select 3-wire connection.

Resistance of the cable from the earth electrode to the instrument has a direct influence on measuring results.

In order to minimize error caused by measurement cable resistance, a short cable with a large cross section should be used to connect the earth electrode to jack “E” for measurements performed with a 3-wire setup. Connector cable resistance can be measured with the 2-wire method (see chapter 6.7 on page 24).



#### Note

Measurement cables must be well insulated in order to avoid shunting. In order to reduce coupling influence to a minimum, measurement cables should neither cross one another, nor should they run parallel to each other over long distances.

Measurement is performed as described in chapter 6.4 on page 16.

#### 4-Wire Connection




Figure 3 Measuring Earthing Resistance with a 4-Wire Test Setup

4-wire connection is used in the event of excessive cable resistance between the earth electrode and the test instrument.

- Position the probe at least 20 meters, and the auxiliary earth electrode at least 40 meters from the earth electrode (see also Figure 3 on page 19).
- Make sure that contact resistance between the probe and the soil is not too great.
- The earth electrode is connected to jacks “E” and “ES” with separate cables for 4-wire connection, the probe is connected to jack “S” and the auxiliary earth electrode is connected to jack “H”.

- Press the **RE4-P** key in order to select 4-wire connection.

Cable resistance from the earth electrode to jack “E” at the instrument is not included in the measurement with this test setup.



#### Note

Measurement cables must be well insulated in order to avoid shunting. In order to reduce coupling influence to a minimum, measurement cables should neither cross one another, nor should they run parallel to each other over long distances.

Measurement is performed as described in chapter 6.4 on page 16.

#### Potential Gradient

Suitable positioning of the probe and the auxiliary earth electrode can be determined by observing voltage characteristics and dissipation resistance in the ground.

The test current which is generated by the test instrument and conducted through the earth electrode and the auxiliary earth electrode causes voltage distribution around the earth electrode and the auxiliary earth electrode in the form of a potential gradient (see also Figure 5 on page 20). Resistance distribution is analog to voltage distribution.

Earth electrode and auxiliary earth electrode dissipation resistance are generally different. For this reason, the two potential gradients are not symmetrical.

#### Dissipation Resistance of Earth Electrodes with Minimal Spread

Positioning of the probe and the auxiliary earth electrode is extremely important for correct determination of earth electrode dissipation resistance. The probe must be positioned between the earth electrode and the auxiliary earth electrode in the so-called ground reference plane (see also Figure 4 on page 20).

The characteristic resistance curve is thus practically horizontal within the ground reference plane.

Proceed as follows in order to select suitable probe and auxiliary earth electrode resistances:

- Position the auxiliary earth electrode approximately 40 meters from the earth electrode.
- Position the probe halfway between the earth electrode and the auxiliary earth electrode and measure earthing resistance.

- Move the probe from its original position 2 to 3 meters closer to the earth electrode, and then 2 to 3 meters closer to the auxiliary earth electrode, and measure earthing resistance at each position.

If the same measured value results from all 3 measurements, the correct earthing resistance value has been obtained and the probe is in the ground reference plane.

However, if these 3 measured values differ from one another, either the probe is not in the ground reference plane, or the characteristic resistance curve is not horizontal at the point at which the probe has been driven into the ground.




Figure 4 Characteristic Voltage Curve in Homogenous Soil between Earth Electrode E and Auxiliary Earth Electrode H




Figure 5 Probe S lies outside of the overlapping potential gradients on a vertical line between earth electrode E and auxiliary earth electrode H.

In such cases, correct measurement results can be obtained either by increasing the distance between the earth electrode and the auxiliary earth electrode, or by moving the probe along the vertical line between the earth electrode and the auxiliary earth electrode (see also Figure 5 on page 20). Moving the probe along this vertical line removes it from the zones of influence of the earth electrode and the auxiliary earth electrode.

#### Dissipation Resistance of Earth Electrodes with Large Spread

Significantly greater distances to the probe and the auxiliary earth electrode are required for measurements performed at larger earthing systems. Distances of 2.5 and 5 times the largest diagonal included in the earthing system are used.

It is especially important to position the probe within the ground reference plane for measurements at large earthing systems, because they frequently demonstrate dissipation resistances of only a few ohms or less. The probe and the auxiliary earth electrode should be positioned at a right angle to the largest longitudinal extension of the earthing system. Dissipation resistance must be kept to a minimum, and several earth spikes should be used if necessary and connected to each other (at a distance of 1 to 2 meters from one another).

However, larger distances to the probe are frequently impossible in practice due to physical obstacles.

If this is the case, proceed as shown in Figure 6 on page 21.

- Auxiliary earth electrode H is positioned as far as possible from the earthing system.
- The area between the earth electrode and the auxiliary earth electrode is measured at equidistant points (in steps of approx. 5 meters).

- Measured resistance values are subsequently displayed as a table, and then as a graphic representation (curve I in Figure 6 on page 21).

If a parallel line is drawn through inflection point S1 to the abscissa, the resistance curve is divided into two parts by this line.

Measured from the ordinate, the bottom portion results in the sought after dissemination resistance of the earth electrode  $R_{A/E}$ . The upper value represents dissemination resistance of the auxiliary earth electrode  $R_{A/H}$ . The dissemination resistance of the auxiliary earth electrode should be less than 100 times the dissemination resistance of the earth electrode with a test setup of this type.

If the characteristic resistance curve does not include a well defined horizontal section, measurement should also be performed after changing the position of the auxiliary earth electrode. The new characteristic resistance curve must then be entered to the first diagram and the abscissa scale must be changed such that both auxiliary earth electrode positions are identical. The originally determined dissemination resistance value can be double-checked with deflection point S2 (see also Figure 6 on page 21).

#### Instructions for Measurements on Unfavorable Terrain

In the event of extremely unfavorable terrain (e.g. sandy ground after a lengthy dry period), auxiliary earth electrode and probe resistance values can be reduced to allowable values by watering the ground around the auxiliary earth electrode and the probe.

If this watering is not sufficient, several earth spikes can be connected to the auxiliary earth electrode in parallel.

In mountainous terrain or if the ground is quite rocky and spikes cannot be driven into the earth, a wire mesh with a mesh size of 1 cm and a surface area of approximately 2 square meters can be used. The wire mesh must be laid flat onto the ground and doused with soda water or saltwater, and may also be weighted down with sacks full of moist soil.

Curve I (CI)		Curve II (CII)	
m	$\Omega$	m	$\Omega$
5	0.9	10	0.8
10	1.28	20	0.98
15	1.62	40	1.60
20	1.82	60	1.82
25	1.99	80	2.00
30	2.12	100	2.05
40	2.36	120	2.13
60	2.84	140	2.44
80	3.68	160	2.80
100	200	200	100

S1, S2 = Inflection point  
 CI = Curve I  
 CII = Curve II




Figure 6 Measuring Earthing Resistance at a Large Earthing System

## 6.6 Measuring Soil Resistivity



### Note

We recommend using measuring accessories sets for earth resistance measurements which are listed as optional accessories (see chapter 1 on page 5).

The dissemination resistance value of a given earth electrode is dependent upon soil resistivity. Soil resistivity must be known in order to allow for advance calculation of dissemination resistance for the design of earthing systems.

Soil resistivity  $\rho_E$  (see also chapter 4 on page 9) can be measured with the GEOHM C earth tester in accordance with the Wenner method.

Four earth spikes of greatest possible length are driven into the ground in a straight line separated from one another by distance  $a$ , and are connected to the test instrument (see Figure 7).

The earth spikes are usually 30 to 50 cm long. Longer earth spikes can be used in poorly conducting soils (sandy soil etc.). The depth to which the earth spikes are driven into the ground may not exceed  $1/20$  of distance  $a$ .



### Note

Erroneous measurement results may occur if pipes, cables or other metallic underground lines run parallel to the measuring circuit.

Measurement is performed as described in chapter 6.4 on page 16. Enter distance  $a$ , and soil resistivity is displayed.





Figure 7 Measuring Soil Resistivity

**Soil resistivity** is calculated in accordance with the following formula:

$$\rho_E = 2\pi \cdot a \cdot R$$

where:

$$\pi = 3.1416$$

$a$  = distance between earth spikes in meters

$R$  = calculated resistance value in  $\Omega$  (this value corresponds to  $R_E$  as determined by means of the 4-wire measurement setup)

### 6.6.1 Geologic Surveys

Except in extreme cases, soil is measured to a depth which is approximately equivalent to distance  $a$  between the earth spikes. It is thus possible to draw conclusions concerning various layers within the ground by varying the distance between the earth spikes. Highly conductive layers (water table) within which earth electrodes are best positioned can thus be located within otherwise poorly conducting surroundings.

Soil resistivity is subject to great fluctuation which may result from various conditions such as porosity, moistness, concentration of salts dissolved in ground water and climatic fluctuations.

Soil resistivity  $\rho_E$  characteristics as influenced by season (ground temperature and negative temperature coefficient of the ground) closely resemble a sine wave.




Figure 8 Soil resistivity  $\rho_E$  in as influenced by season without taking precipitation into consideration (earth spike depth < 1.5 m)

The following table shows typical soil resistivity for several types of soil.

Type of Soil	Soil Resistivity $\rho_E$ [ $\Omega\text{m}$ ]
Wet bog soil	8 ... 60
Arable fields, loam and clay, moist gravel	20 ... 300
Moist, sandy soil	200 ... 600
Dry sandy soil, dry gravel	200 ... 2000
Rocky ground	300 ... 8000
Bedrock	$10^4$ ... $10^{10}$

Tabelle 1 Soil Resistivity  $\rho_E$  for Various Types of Soil

### 6.6.2 Calculating Dissemination Resistance

The following table includes formulas for calculating dissemination resistance for various types of earth electrodes. These rule-of-thumb formulas are entirely adequate for practical application.

Number	Earth Electrode Type	Formula	Auxiliary Information
1	Earth strip (crow's foot earth electrode)	$R_A = \frac{2 \cdot \rho_E}{l}$	—
2	Earth rod	$R_A = \frac{\rho_E}{l}$	—
3	Ring earth electrode	$R_A = \frac{2 \cdot \rho_E}{3D}$	$D = 1.13 \cdot \sqrt[2]{F}$
4	Mesh earth electrode	$R_A = \frac{2 \cdot \rho_E}{2D}$	$D = 1.13 \cdot \sqrt[2]{F}$
5	Earth plate	$R_A = \frac{2 \cdot \rho_E}{4,5 \cdot a}$	—
6	Hemispherical earth electrode	$R_A = \frac{\rho_E}{\pi \cdot D}$	$D = 1.57 \cdot \sqrt[3]{J}$

Tabelle 2 Formulas for the Calculation of Dissemination Resistance  $R_A$  for Various Types of Earth Electrodes

$R_A$  = Dissemination resistance ( $\Omega$ )

$\rho_E$  = Soil resistivity ( $\Omega\text{m}$ )

$l$  = Earth electrode length (m)

$D$  = Ring earth electrode diameter, diameter of the equivalent circular area of a mesh earth electrode or diameter of a hemispherical earth electrode (m)

$F$  = Surface area (square meters) enclosed by a ring or a mesh earth electrode

$a$  = Edge length (m) of a rectangular earth plate,  $a$  is defined as follows for rectangular earth plates:  $\sqrt{b \times c}$ , where  $b$  and  $c$  are the two sides of the rectangle.

$J$  = Volume (cubic meters) of an individual foundation

## 6.7 Measuring Ohmic Resistance

The resistance of liquid and solid conductors can be measured with the GEOHM C earth tester, as long as they are capacitance and induction-free.

### 6.7.1 2-Wire Connection

- ⇒ Connect the resistance to be measured  $R_X$  between jacks E and H.




Figure 9 Measuring Ohmic Resistance with a 2-Wire Test Setup



#### Note

Cable resistance can be measured with this test setup.

### 6.7.2 4-Wire Connection

- ⇒ Use 4-wire connection if cable resistance is not to be included in the measurement results.






Figure 10 Measuring Ohmic Resistance with a 4-Wire Test Setup



## 7 Database Function

Displayed measurement data can be saved individually for each measurement to the internal database either with or without a comment.



### Attention!

Data loss / temporary storage.

The data are stored in the internal RAM as long as the associated battery supplies the necessary voltage.


Upload your data manually from the instrument at regular intervals in order to avoid data loss. It is not possible to read out the data digitally from the instrument.

We assume no liability for data loss.

In order to assign the individual measured values to various buildings, customers etc., a data record must first be created with its own memory address.

### 7.1 Creating a Data Record – Data Function

- ⇨ Press the data softkey.




- ⇨ First, enter the desired memory address with the softkeys. After acknowledging this entry with the **START** key (press at center), the cursor appears at the first entry position (BUILDING).

No entry is required for the customer ID field, as long as measurements are only performed for a single company.

The M-TYPE field (measurement type) is used to designate what kind of measurement is involved. This entry is required in order to generate a report with PS3 test instrument software for lightning protection systems.

M-TYPE Setting	Significance
D	Continuity to metallic installations
DG	Continuity to metallic gas lines
DW	Continuity to metallic water lines
DL	Continuity to metallic ventilation systems
D1, D2, D3, D4	Continuity to other, user-defined types of metallic systems
U	Contact resistance measurement at all measuring points in order to determine continuity of all conductors. The number assigned to the measurement designates resistance between specific test joints, e.g. measurement number 1 indicates resistance between test joints 1 and 2, measurement 2 between test joints 2 and 3 etc.
E	Measurement of earth dissemination resistance from individual earth electrodes with open test joints
!	Measurement of earth dissemination resistance for the entire system with closed test joints

- ⇨ Entries can be made to the BUILDING, M-TYPE and CUSTOMER ID fields one after the other, and a building designation can be entered with the help of the softkeys.



### Data Entry:

The desired alphanumeric characters can be displayed with the help of the **←** and **→** keys, and then selected with the appropriate

softkey.

Control characters are entered in the same way and have the following functions:

- ←: Move cursor to the left (without deleting characters)
- : Move cursor to the right (without deleting characters)
- ⌵: Same function as the **START** key

After a character has been selected, the cursor moves one place to the right. If the ⌵ character is entered or the **START** key is pressed (press at center), the cursor moves to the next field. After the BUILDING, M-TYPE and CUSTOMER-ID fields have been completed and entries have been acknowledged with the ⌵ command, they are highlighted at the display. After acknowledging once more with the ⌵ character, a designation for the currently selected building can be entered.

## 7.2 Saving Measured Values to Memory – STORE Function

- Start the desired measurement. The STORE softkey is displayed after the measurement instead of the INFO key.  
The STORE key is not displayed until after a given amount of time has elapsed for measurements which are performed without the **START** key, so that the operator can first query the help text with the INFO key.
- The displayed measurement values are stored to the currently selected database memory address by briefly acknowledging with the STORE key. The key is briefly displayed as an inverse image during storage to memory.
- Pressing and holding the STORE key allows for the entry of a comment, and storage of the current measurement.


### Entering a Comment:

Display the desired alphanumeric character with the ← or the → key and select the desired character with the corresponding softkey. Control characters are displayed in the same way and have the following functions:

- ←: Backspace and delete
- ⌵: Same function as the **START** key



After each character has been selected, the cursor moves one place to the right. Already entered characters can be deleted in reverse by pressing and holding any softkey (except for ⌵).

After entry of up to 15 characters, save the measurement values and the comment by acknowledging with the **START** key (press at center). The following message appears: "Saving data".



### 7.3 Querying Data Records – View Function


- Press the View key.
- You can scroll forward through the memory addresses with the **➡** key, or backwards with the **⬅** key.
- After the memory address has been opened, the individual data records which have been stored to memory along with consecutive numbers can be queried with the Prev. and Next softkeys.



If you discover that a measurement value for the currently selected earthing system is missing, the required measurement can be performed immediately.


### 7.3.1 Deleting a Data Record from within a Memory Address – View Function

- Press the Del key. No security requests appear. Data record numbering is changed as soon as an individual data record is deleted.



### 7.3.2 Deleting a Memory Address – Data Function

- Press the Data key.
- Enter blanks to the data fields BUILDING, M-TYPE and CUSTOMER ID. After these fields have been entirely overwritten with blanks, they are displayed as inverse images.




- Acknowledge with the **START** key (press at center). All data from the selected memory address are deleted.


### 7.3.3 Delete All Memory Addresses – Data Function

Up to 250 data records can be stored to memory. The memory is full when the triangle to the right of the "MEMORY:" parameter is entirely filled in. The entire memory, i.e. all data records from all memory addresses, can be deleted at once. We recommend uploading your data manually before deletion.


- ⇒ Press the Data key.



- ⇒ Enter memory address "000". A security request appears after acknowledgement with the **START** key (press at center).



- ⇒ Acknowledge by simultaneously pressing O and K to delete all data from memory. The indicator to the right of the "MEMORY:" parameter appears empty. Memory address "001" is displayed at the left. New data can now be entered for this address, or the database can be exited (press **↵** or **START 9** times).



If the message shown above appears when the test instrument is switched on, you are provided with the opportunity of uploading all data manually before deleting the memory in order to correct the error.

## 8 Characteristic Values

Meas. Qty.	Display range	Measuring Range	Impedance, Test Current	Intrinsic Uncertainty	Measuring Uncertainty
$R_E$	0.01 ... 20 $\Omega$	1.0 ... 20 $\Omega$	10 mA	$\pm(3\%rdg.+6d)$	$\pm(10\%rdg.+6d)$
	0.1 ... 200 $\Omega$	5 ... 200 $\Omega$	1 mA		$\pm(10\%rdg.+6d)$
	1 $\Omega$ ... 2 k $\Omega$	50 $\Omega$ ... 2 k $\Omega$	100 $\mu$ A		$\pm(10\%rdg.+6d)$
	10 $\Omega$ ... 20 k $\Omega$	500 $\Omega$ ... 20 k $\Omega$	100 $\mu$ A		$\pm(10\%rdg.+6d)$
	10 $\Omega$ ... 50 k $\Omega$	500 $\Omega$ ... 50 k $\Omega$ <sup>1)</sup>	100 $\mu$ A		$\pm(16\%rdg.+10d)$
$U_{\text{---}}$ <sup>2)</sup>	1.0 ... 99.9 V 100 ... 250 V	10 ... 250 V	500 k $\Omega$	$\pm(2\%rdg.+2d)$	$\pm(4\%rdg.+3d)$
$U_{\text{---}}$ <sup>3)</sup>	0 ... 99.9 V 100 ... 300 V				
$f$ <sup>3)</sup>	15 ... 99.9 Hz 100 ... 400 Hz	45 ... 200 Hz	500 k $\Omega$	$\pm(0.1\%rdg.+1d)$	$\pm(0.2\%rdg.+1d)$

<sup>1)</sup> Manual measuring range selection only, for resistance measurements see chapter 6.7

<sup>2)</sup> as from software version AD

<sup>3)</sup> For sinusoidal measured quantities only


Output Voltage max. 50 V<sub>TRMS</sub> at 128 Hz  $\pm$ 0.5 Hz

### Reference Conditions

Ambient Temperature 23 °C  $\pm$ 2 K  
 Relative Humidity 40% ... 60%  
 Battery Voltage 5.5 V  $\pm$ 1%  
 Line Frequency 50 Hz  $\pm$ 0.2 Hz  
 Line Voltage Waveshape sine (deviation between effective and rectified value < 1%)

### Nominal Conditions of Use

Series Mode Interference Voltage < 3 V AC DC  
 Additional Error due to Probe and  
 Aux. Earth Electrode Resistance < 5% pf ( $R_E+R_H+R_S$ )  
 Max. Probe Resistance < 70 k $\Omega$   
 Max. Auxiliary Earth  
 Electrode Resistance < 50 k $\Omega$   
 Max. Earth and Auxiliary  
 Earth Electrode Resistance  $\leq$  50 k $\Omega$ , see graph  $R_E$  as a function of  $R_H$



### Ambient Conditions

Nominal Range of Use 0 °C ... +40 °C  
 Operating Temperature -10 °C ... +50 °C  
 Storage Temperature -20 °C ... +60 °C (without batteries)  
 Relative Humidity max. 75%, no condensation allowed to 2000 m  
 Elevation

### Power Supply

**Batteries**  
 4 ea. 1.5 V baby cell (4 x C-size)  
 (alkaline manganese per IEC LR14)  
 Battery Voltage 4.6 ... 6.5 V  
 Battery Service Life 30 hours or 1000 measurements at  $R_E$   
 (with 10 s on-time and automatic device shutdown after each measurement, without display illumination)

**Rechargeable Batteries** NiCd or NiMH  
 Battery Charger NA102 (article no. Z501N) <sup>1)</sup>,  
 3.5 mm dia. jack plug

Charging Voltage / Time 9 V / approx. 14 hours  
 Due to their reduced charging capacity, fewer measurements can be performed with rechargeable batteries than with normal batteries as a rule.

<sup>1)</sup> Battery charger NA102 Z501N is not included in the standard equipment and is no longer available as an optional accessory.

## Electrical Safety

Safety Class	II per DIN EN 61140/VDE 0140-1
Operating Voltage	250 V
Test Voltage	2.3 kV
Measuring Category	250 V CAT II
Fouling Factor	2
Fuse	F0, 1H250V
EMC	IEC 61326-1/EN 61326-1

## Data Interface <sup>1)</sup>

Type	infrared interface (SIR/IrDa) bidirectional, half-duplex
Format	9600 baud, 1 start bit, 1 stop bit, 8 data bits, no parity, no handshake
Range	max. 10 cm, recommended distance: < 4 cm

## Mechanical Design

Display	dot matrix: 64 x 128 pixels, illuminated
Dimensions	275 mm x 140 mm x 65 mm (without cables)
Weight	approx. 1.2 kg with batteries
Protection	housing: IP 54 per EN 60529 with pressure compensating diaphragm made of microporous ePTFE, non-aging, dia. 8 mm in bat- tery compartment cover

Extract of table on the meaning of IP codes

IP XY (1 <sup>st</sup> digit X)	Protection against foreign object entry	IP XY (2 <sup>nd</sup> digit Y)	Protection against the penetration of water
0	not protected	0	not protected
1	≥ 50.0 mm Ø	1	vertically falling drops
2	≥ 12.5 mm Ø	2	vertically falling drops with enclosure tilted 15°
3	≥ 2.5 mm Ø	3	spraying water
4	≥ 1.0 mm Ø	4	splashing water
5	dust protected	5	water jets
6	dust-tight	6	powerful water jets

<sup>1)</sup> obsolete (function no longer available)

## Display Values including Allowances for Measuring Error

Table for the determination of maximum display values for low earth resistances by making allowances for the tester's measuring error:

Limit Value	Maximum Display Value	Limit Value	Maximum Display Value
1.00 Ω	0.84 Ω	50.0 Ω	44.4 Ω
2.00 Ω	1.74 Ω	100 Ω	89.4 Ω
5.00 Ω	4.44 Ω	500 Ω	444 Ω
10.0 Ω	8.94 Ω	1.00 kΩ	894 Ω
20.0 Ω	17.4 Ω	5.00 kΩ	4.44 kΩ

## 9 CE Declaration

This instrument fulfills the requirements of the applicable EU guidelines and national regulations. We confirm this with the CE marking. The relevant declaration of conformity can be obtained from Gossen Metrawatt GmbH.

## 10 Maintenance

### 10.1 Housing

No special maintenance is required for the housing. Keep outside surfaces clean. Use a slightly dampened cloth and/or a special purifier for synthetic material for cleaning. Avoid the use of cleansers, abrasives and solvents.



### Attention!

For the following reasons, the housing may not be opened by the operator:

- Unexpected problems may occur during reassembly.
- Sealing requirements are no longer fulfilled.

### 10.2 Fuses

If the fuse has blown due to an overload, an appropriate error message appears at the LCD ( $R_{H1} > \max$ ). However, the instrument's voltage measuring range is still functional.

## Replacing the Fuse

The fuse can be accessed easily from the outside of the instrument, and is located to the left of the charging socket.

- Remove the threaded fuse cap with the help of a suitable tool (e.g. a screwdriver) by pressing and turning counterclockwise.



### Attention!

Incorrect fuses may cause severe damage to the test instrument. Only original fuses from Gossen Metrawatt GmbH assure the required protection by means of suitable breaking characteristics (article no. 3-578-235-01).

Bridging or repairing fuses is prohibited!

The instrument may be damaged if fuses with other current ratings, blowing or breaking characteristics are used!

- Remove the defective fuse and replace it with a new replacement fuse. Replacement fuses are located in the battery compartment.
- Insert the new fuse and the cap together, and lock into place by turning clockwise.
- Replace the battery compartment cover and secure with the screws.

## 10.3 Recalibration

The respective measuring task and the stress to which your measuring instrument is subjected affect the ageing of the components and may result in deviations from the guaranteed accuracy.

If high measuring accuracy is required and the instrument is frequently used in field applications, combined with transport stress and great temperature fluctuations, we recommend a relatively short calibration interval of 1 year. If your measuring instrument is mainly used in the laboratory and indoors without being exposed to any major climatic or mechanical stress, a calibration interval of 2-3 years is usually sufficient.

During recalibration\* in an accredited calibration laboratory (DIN EN ISO/IEC 17025) the deviations of your instrument in relation to traceable standards are measured and documented. The deviations determined in the process are used for correction of the readings during subsequent application.

We are pleased to perform DAkkS or factory calibrations for you in our calibration laboratory. Please visit our website at [www.gossenmetrawatt.com](http://www.gossenmetrawatt.com) (→ Company → Quality and Certificates → DAkkS Calibration Center).

By having your measuring instrument calibrated regularly, you fulfill the requirements of a quality management system per DIN EN ISO 9001.

\* Verification of specifications or adjustment services are not part of the calibration. For products from our factory, however, any necessary adjustment is frequently performed and the observance of the relevant specification is confirmed.

## 11 Device Return and Environmentally Compatible Disposal

The **instrument** is a category 9 product (monitoring and control instrument) in accordance with ElektroG (German Electrical and Electronic Device Law). This device is subject to the WEEE directive. Furthermore, we make reference to the fact that the current status in this regard can be accessed on the Internet at [www.gossenmetrawatt.com](http://www.gossenmetrawatt.com) by entering the search term WEEE.

We identify our electrical and electronic devices in accordance with WEEE 2012/19/EU and ElektroG with the symbol shown to the right per DIN EN 50419 .

These devices may not be disposed with the trash. Please contact our service department regarding the return of old devices.

If you use **batteries** or **rechargeable batteries** in your instrument or accessories which no longer function properly, they must be duly disposed of in compliance with the applicable national regulations.

Batteries or rechargeable batteries may contain harmful substances or heavy metal such as lead (Pb), cadmium (Cd) or mercury (Hg).

The symbol shown to the right indicates that batteries or rechargeable batteries may not be disposed of with the trash, but must be delivered to collection points specially provided for this purpose.



## 12 Repair and Replacement Parts Service, Calibration Center\* and Rental Instrument Service

If required please contact:

GMC-I Service GmbH  
**Service Center**  
Beuthener Straße 41  
90471 Nürnberg, Germany  
Phone +49 911 817718-0  
Fax +49 911 817718-253  
E-mail: [service@gossenmetrawatt.com](mailto:service@gossenmetrawatt.com)

This address is only valid in Germany.

Please contact our representatives or subsidiaries for service in other countries.

### \* **DAkKS Calibration Laboratory for Electrical Quantities** **D-K-15080-01-01 accredited per DIN EN ISO/IEC 17025**

Accredited measured quantities: direct voltage, direct current values, DC resistance, alternating voltage, alternating current values, AC active power, AC apparent power, DC power, capacitance, frequency and temperature

## Competent Partner

Gossen Metrawatt GmbH is certified in accordance with DIN EN ISO 9001.

Our DAkKS calibration laboratory is accredited by the Deutsche Akkreditierungsstelle GmbH (German accreditation body) under registration number D-K-15080-01-01 in accordance with DIN EN ISO/IEC 17025.

We offer a complete range of expertise in the field of metrology: from **test reports** and **proprietary calibration certificates** right on up to **DAkKS calibration certificates**.

Our spectrum of offerings is rounded out with free **test equipment management**.

An **on-site DAkKS calibration station** is an integral part of our service department. If errors are discovered during calibration, our specialized personnel are capable of completing repairs using original replacement parts.

As a full service calibration laboratory, we can calibrate instruments from other manufacturers as well.

## 13 Product Support

If required please contact:

Gossen Metrawatt GmbH  
**Product Support Hotline**  
Phone +49 911 8602-0  
Fax +49 911 8602-709  
E-Mail [support@gossenmetrawatt.com](mailto:support@gossenmetrawatt.com)

---

© Gossen Metrawatt GmbH

Prepared in Germany • Subject to change without notice / Errors excepted • A PDF version is available on the Internet

All trademarks, registered trademarks, logos, product names, and company names are the property of their respective owners.

 **GOSSEN METRAWATT**  
Gossen Metrawatt GmbH  
Südwestpark 15  
90449 Nürnberg • Germany

Phone +49 911 8602-111  
Fax +49 911 8602-777  
E-Mail [info@gossenmetrawatt.com](mailto:info@gossenmetrawatt.com)  
[www.gossenmetrawatt.com](http://www.gossenmetrawatt.com)