

Firmware history

Release Notes LINAX PQ5000MOBCLM



Update of PQ5000MOBCLM

The update package of the PQ5000MOBCLM contains two firmware images, one for the base unit and the other one for the CL option, which enables communication with the current modules via the Current Link.

The firmware update should be performed in the following way:

- 1. Possible upgrade of the updater, if not using the EasyUpdater software
- 2. Update of the firmware of the base unit
- 3. Update of the firmware of the CL option

GMC INSTRUMENTS

Camille Bauer Metrawatt AG Aargauerstrasse 7 CH-5610 Wohlen / Schweiz Telefon: +41 56 618 21 11 Telefax: +41 56 618 35 35 E-Mail: info@cbmag.com



Version	Change log
V3.09 – 9755 (2023/06/15)	 New features Use of special characters in names of Current Link modules Fixes Settings of recording duration for PQ events No recording of current events Meter contents of L1, L2, L3 equal to system value After a factory reset PQ report could no longer be created Incorrect scaling of current plots in PQ displays if unit [kA] required Reset of meter contents
V3.07 – 9485 (2023/04/03)	Official product release of LINAX PQ5000MOBCLM