

# MAVOWATT 210

# **Three-Phase Power and Energy Logger**

- Accurate, three-phase, bidirectional power and energy logger to identify and record common PQ issues
- Portable, small and compact
- 3+1 voltage and 4 current channels
- 4 voltage leads and 3 flexible AC Rogowski current probes
- Suitable for monitoring single, two, and three phase applications
- Ethernet and USB
- Integrated web server for easy configuration and real time data monitoring
- Dran-View XP software
- Softcase



# **Applications**

Various local or remote power monitoring applications:

- Energy audits according to DIN EN 16247-1
- Demand side management
- Basic PQ surveys
- Check metering
- Sub metering
- Tenant metering
- Alternative energy production
- Energy cost allocation
- Load profiling
- Power factor studies
- Residential applications including energy using and PQ detection

### **Features**

- 3+1 voltage channels Direct measurements up to 600 VRMS, CAT III
- 4 current channels MAVOWATT 210 Rogowski or hinged CTs (see Optional Accessories)
- Measures: V, I, W (P), VA (S), VAR (Q), PF, demand, energy & much more
- PQ disturbance detector Detects and records trends of RMS sags/dips, swells, current changes (IEC 61000-4-30 1/2 cycle methods)
- Harmonic measurements & recording Vthd, lthd. Measurements according to IEEE 519-2014/ IEC 61000-4-7
- Integrated web browser for setup, real time metering, and data transfer
- Dran-View XP software for analysis and reporting
- 7 hours battery runtime
- Automatic wiring verification LEDs indicate wiring errors
- Ethernet and USB communications
- Modbus, BACnet®

3-447-113-03 2/5.22

# **MAVOWATT 210**

**Three-Phase Power and Energy Logger** 

# **Technical Data**

#### **Mechanical Design**

Housing	Approx. $6.4 \times 8.9 \times 18.8$ cm
$(W \times H \times D)$ :	
Weight:	Approx. 0.64 kg
Protection:	IP50 (in vertical position)

#### **Ambient Conditions**

0 +45 °C
−15 +55 °C
max. 2000 m above sea level
5% to 95%, no condensation allowed

### **Power Supply**

AC Power Supply	Range: 90 to 264 VAC, 47 to 63 Hz
	Consumption: 15 W max.
Internal Battery	Rechargeable lithium ion battery 3.6 V, 7.2 Ah
	Run time: 7 hours (typical) Charge time: 15 hours (typical)

### **Electrical Safety**

Protection category: CAT II Pollution degree: 2

#### **Electrical Safety for Measurement**

Measuring categoryCAT IIIPollution degree2

#### **Data Interfaces**

Ethernet	10 Mbit/s
USB	2.0
Protocols	Modbus, BACnet®
Internal Memory Storage Capacity	8 GB

# **Relevant Standards**

The instrument has been manufactured and tested in accordance with the following safety regulations:

EN 61326	Class A, Electromagnetic Compatibility - Electrical equipment for Measurement, Control and Laboratory use
CISPR 11	Class A Limits Of Radio Disturbance and Immunity Measuring Apparatus
EN 61000-4-2	Electrostatic Discharge Immunity
EN 61000-4-3	Electromagnetic Field Immunity
EN 61000-4-4	Electrical Fast Transient Burst Immunity
EN 61000-4-5	Surge Immunity
EN 61000-4-6	Immunity to Conducted Disturbances
DIN EN 60529/ IEC 60529	Degrees of protection provided by en- closures (IP Code)
EN 61010-1	Safety Requirements of Electrical Equip- ment for Measurement, Control, and Laboratory Use

# **Characteristic Values)**

attery vical)	General	Sampling frequency	32 ksps (recorded and real-time meters), 128 samples per cy- cle (periodic wave- form snapshots)
		Sag/dip, swell trigger resolution	1-cycle (uses IEC 61000-4- 30 Class S methods)
	Voltage	Range	90 to 600 VRMS CATIII
		Accuracy	90 VRMS to 600 VRMS = $\pm 0.1\%$ , < 90 VRMS = $0.5\%$
		Connections	4 safety banana volt- age inputs - 3-phase voltage and 1 neu- tral/reference
	Current	Input	0.333 VRMS full scale, connections: BNC
		Accuracy	±0.1% + probe

# MAVOWATT 210

# **Three-Phase Power and Energy Logger**

Frequency	Range	50 Hz = 45 Hz to 55 Hz, 60 Hz = 55 Hz to 65 Hz	1 1 1	Ethernet cable Software Dran-View XP Softcase
	Accuracy	50/60 Hz: ±0.001 Hz	<b>Opti</b>	onal Accessories
Energy	(True/Active) energy (P)	0.1%	1	Flexible AC current probe based on the Rogowski
Parameters	Reactive energy (Q)	0.1%		principle, 50 – 500 Å,
	Apparent energy (S)	0.1%	-	measuring head length 40 cm (product no. Z840A)
	Fundamental active energy (P)	0.2%	1	Flexible AC current probe based on the Rogowski principle, 150 – 1500 A, measuring head length 40 cm (product no. Z840B)
	Fundamental reactive energy (Q)	0.2%	1	Flexible AC current probe based on the Rogowski principle, 300 – 3000 A,
	Fundamental apparent energy (S)	0.2%	4	measuring head length 40 cm (product no. Z840C)
	Demand	0.2%	1	Split core current transformer MAVOWATT 210 CT- H-5A with connection cable suitable for
Power Parameters	Active power (P)	0.2%	MAVOWATT 210; 600 V CAT III; 5 A; clas	MAVOWATT 210; 600 V CAT III; 5 A; class 0.5; ca- ble opening diameter 10 mm (product no. Z840J)
i alamotoro	Reactive power (Q)	0.2%	1	Split core current transformer MAVOWATT 210 CT-
	Apparent power (S)	0.2%		H-20A with connection cable suitable for
	Fundamental active power (P)	0.2%		MAVOWATT 210; 600 V CAT III; 20 A; class 0.5; cable opening diameter 10 mm
	Fundamental reactive power (Q)	0.2%	1	(product no. Z840K) Split core current transformer MAVOWATT 210 CT-
	Fundamental apparent power (S)	0.2%		H-50A with connection cable suitable for MAVOWATT 210; 600 V CAT III; 50 A; class 0.5;
	Power factor	±0.001%		cable opening diameter 10 mm (product no. Z840L)

# **Scope of Delivery**

Please check for completeness of the set (product no. M840B):

- 1 MAVOWATT 210
- 1 Power pack (IP42)
- 4 Voltage leads with detachable alligator jaw safety clip assembly, maximum jaw opening 20 mm
- Flexible AC current probe based on the Rogowski principle, 50 500 A, measuring head length 40 cm (product no. Z840A)

# **Order Information**

Description		Article number	
MAVOWATT 210	Three-phase power and energy logger	M840B	

For additional information regarding accessories please refer to

- Measuring Instruments and Testers catalog
- www.gossenmetrawatt.com

#### © Gossen Metrawatt GmbH

Prepared in Germany • Subject to change, errors excepted • PDF version available on the Internet

All trademarks, registered trademarks, logos, product names, and company names are the property of their respective owners.

GOSSEN METRAWATT Gossen Metrawatt GmbH Südwestpark 15 90449 Nürnberg • Germany

Phone+49 911 8602-0Fax+49 911 8602-669E-mailinfo@gossenmetrawatt.comwww.gossenmetrawatt.com