

# METRAHIT PM TECH, PM XTRA, PM TUNE, ETECH, EXTRA Professional Multimeters METRAHIT EU PRO & ESPECIAL Special Multimeters

3-349-454-03 12/5.21

- Digital Hand-Held Multimeters with TRMS Measurement amongst other features including:
   VAC TRMS, VAC+DC TRMS, VDC, dB, Hz(V), Hz(A), Ω, V-→-, °C / °F with thermocouple (TC)
- Resolution of 60,000 counts, can be changed to 6000 via the menu, display illumination can be activated for difficult lighting conditions

#### METRAHIT PM TECH / ETECH

- Direct Current measurement with increased accuracy and current measurement, via clamp current transformer and sensors
- Broad range capacitance measurement

#### METRA HIT PM XTRA / TECH / EU PRO & METRAHIT EXTRA / ETECH / ESPCIAL

- Special low-impedance alternating voltage measurement (1 MΩ)
- 1 kHz / -3 dB low-pass filter can be activated
- Temperature measurement with Pt100/Pt1000 resistance sensor

#### METRA HIT PM XTRA / PM TUNE / EXTRA

- Direct current measurement from 10 nA to 10 A, 16 A for short periods
- Temperature measurement with Pt100/Pt1000 resistance sensor
- Broad range capacitance measurement
- TRMS AC and AC + DC bandwidth 100 kHz
- METRAHIT PM TUNE: faster display refresh for adjustment work

#### METRAHIT EU PRO / ESPECIAL

 Special instrument for the performance of measurements at current transformer circuits

# CAT IV









#### **Applications**

The instruments of the Professional series (E and high resolution series) are extremely rugged, reliable digital multimeters with housings made of impact resistant ABS.

With a resolution of 60,000 counts and up to 26 different measuring functions, they've been developed for professional use.

#### **Features**

#### Three Connector Jacks with Automatic Blocking Sockets (ABS) \*

All current ranges are implemented via a single connector jack which prevents any possibility of operator error. Auto-ranging is available in all current measuring ranges. Also the automatic blocking sockets prevent incorrect connection of the measurement cables, as well as selection of the wrong measured values. Danger to the user, the instrument and the device under test resulting from operator error is eliminated to a great extent.

\* Patented (patent no. EP 1801 598, US 7,439,725)

#### **Overload Protection**

The instrument is safeguarded for up to 1000 V in all measuring functions by overload protection. Voltages of greater than 1000 V and current of greater than 10 or 16 A are indicated acoustically. Dangerous contact voltages are indicated when the 1 kHz low-pass filter is activated.

The FUSE display appears at METRA HIT PM XTRA / PM TUNE / EXTRA and METRAHIT PM TECH / ETECH instruments in order to indicate that the fuse for the current measuring input has blown.

#### **RMS Value with Distorted Waveshape**

The utilized measuring method allows a waveshape independent RMS measurement (TRMS AC and AC+DC) for voltage and current (METRA HIT PM XTRA / PM TUNE / EXTRA up to 100 kHz).

#### Selectable Filter for V AC Measurement

A 1 kHz low-pass filter can be selected if required, for example to measure the motor voltage at electronic frequency converters. The input signal is checked by a voltage comparator for dangerous voltages as long as the low-pass filter is activated. A high-voltage symbol appears at the display if dangerous voltage is present.

### Measuring 5 V Square-Wave Signals with the METRA HIT PM XTRA / PM TUNE / EXTRA

This function allows to test circuits and transmission cables by measuring the frequency and the duty cycle of pulses with amplitudes of 2 to 5 V and frequencies of 100 Hz to 1 MHz.

#### Analog Scale for Quick Trend Display - Bar Graph or Pointer

The analog scale (with additional negative range for zero-frequency quantities) allows for faster recognition of measured value fluctuation than is possible with a digital display. The instrument can be switched back and forth between bar graph and pointer display via the menu.

#### **Automatic or Manual Measuring Range Selection**

Measurement functions are selected by a rotary dial and a function key. The measurement range selection is done automatically according to the input signal. Manual measurement range selection is possible via function key.

#### Measurement with current clamps and sensors

Current clamps and sensors are used for current measurements without interrupting the circuit under test and for high currents above 16 Amps. All E series multimeters offer convenient measurement with current clamps.

The measured current value is automatically calculated for the user with the help of the adjustable clamp factor.

#### **Fast Acoustic Continuity Test**

Testing for short circuit connection and circuit interruption is possible with the selector switch in the  $\mathbb{Q}$ ) position. The threshold value for acoustic response can be set to 1, 10, 20 ... 500  $\Omega$  in 10 Ohm steps.

#### Automatic Storage of Measured Values \*

The DATA function automatically saves the digitally displayed measured value after stabilisation in. Acoustic signaling is also used to indicate whether the new measured value deviates from the initial reference value by less or more than 0.1% of the measuring range.

\* Patented

#### Min-Max Data Storage

Comparable to the slave-pointer function of an analog instrument, the device saves the highest and lowest measured values after the MIN/MAX function has been activated or reset. These extreme values can be queried at the display.

#### Battery Charging Status - Power Saving Circuit

The battery charging status is indicated by means of four symbols. The device is switched off automatically if the measured value remains unchanged for a period of between 10 and 59 minutes (adjustable), and if none of the controls are activated during this time. Automatic shutdown can be deactivated by switching the instrument to continuous operation.

The standby mode of the infrared interface can be switched off.

#### **Protective Rubber Holster for Rugged Conditions**

The instrument is protected against damage in the event of impacts or dropping by means of a soft rubber holster with tilt stand and test probe holder. The rubber material also assures that the instrument does not slide if it is set up on a vibrating surface.

#### **Infrared Data Interface**

The device can be remotely configured, and momentary and stored measurement data can be read out via the bidirectional infrared interface. The USB X-TRA interface adapter and METRAwin10 software are required (see accessories). Interface protocol and device driver software for LabVIEW (National Instruments<sup>TM</sup>) are available upon request.

#### **DAkkS Calibration Certificate**

Each multimeter is individually adjusted, subjected to final inspection and calibrated. Adherence to the specification is confirmed by means of the included DAkkS calibration certificate, which is valid worldwide (recognized by EA and ILAC. Upon expiry of the user-defined calibration interval (recommended intervals: 1 to 3 years) the multimeters can be recalibrated at our DAkkS calibration laboratory at any time.

#### **Applicable Regulations and Standards**

IEC/DIN EN 61010-1 VDE 0411-1	Safety requirements for electrical equipment for measurement, control and laboratory use
DIN EN 61 326-1 VDE 0843-20-1	Electrical equipment for measurement, control and laboratory use  – EMC requirements – Part 1: General requirements
DIN EN 60529 DIN VDE 0470-1  Test instruments and test procedures – degrees of protection provided by enclosures (IP co	

#### **Functional overview**

T dilotional ovol viov			
Function	PM XTRA PM TUNE Extra	PM TECH Etech	EU PRO Especial
$ \begin{array}{l} \text{Voltage V}_{DC} \\ \text{(Ri} \geq 9 \ \text{M}\Omega) \end{array} $	✓	1	✓
$ \begin{array}{l} \text{Voltage V}_{\text{AC}} \text{ TRMS} \\ \text{(Ri} \geq 9 \text{ M}\Omega) \end{array} $	1	1	✓
Voltage Lo <sup>1)</sup> $V_{AC}$ TRMS (Ri = 1 M $\Omega$ )	1	1	✓
$ \begin{array}{l} \text{Voltage V}_{\text{AC+DC}}  \text{TRMS} \\ \text{(Ri} \geq 9  \text{M}\Omega) \end{array} $	1	1	1
Frequency Hz @ V <sub>AC</sub> or @ Lo <sup>1)</sup> V <sub>AC</sub>	300 kHz	300 kHz	300 kHz
Low-pass filter 1 kHz	(	V <sub>AC</sub> / @ LoV <sub>AC</sub>	
Bandwidth @ V <sub>AC+DC</sub> or V <sub>AC</sub>	100 kHz	20 k	kHz
Frequency MHz @ 5V TTL	0.1 Hz1 MHz	_	_
Duty cycle %	2.0 % 98 %	_	_
Voltage level measurement dB	/	/	1
Resistance $\Omega$	✓	/	1
Continuity test @I <sub>CONST</sub> = 1 mA	1	1	✓
Diode measurement @I <sub>CONST</sub> = 1 mA	1	1	✓
Temperature measurement °C/°F with thermocouple (TC)		Type K	
Temperature measurement °C/°F RTD	Pt100/	/Pt1000	_
Capacitance measurement F	✓	/	_
Current A <sub>DC</sub>	600 mA/6 mA	60 mA/600 mA	
Current A <sub>AC+DC</sub> TRMS	60 mA/600 mA	6 A/10 A (16 A)	6 A/10 A (16 A)
Current A <sub>AC</sub> TRMS	6 A/10 A (16 A)	, ,	
Bandwidth @ A <sub>AC+DC</sub> or A <sub>AC</sub>		10 kHz	
Frequency Hz @ A <sub>AC</sub>		60 kHz	
Measurement with clamp ammeter with adjustable transfer factor		//A \/A	mV / A A / A
Data logger function <sup>2)</sup> (memory)	16 Mbit	_	_
Relative value measurement ∆REL	✓	✓	1
Zero point ZERO	✓	/	/
MIN/MAX/DATA Hold	/	/	/
IR-interface (38.4 kBd)	✓	/	✓
Power pack connector socket	/	_	_
Protective rubber holster	/	/	/
Fuse	10 A / 1000 V	10 A / 1000 V	_
Protection 3)	IP52	IP52	IP52
Measuring category	600 V	V CAT III CAT IV	600 V CAT II
Calibration	DAkkS	DAkkS	DAkkS

Alternating voltage measurement with specially reduced input impedance

#### Included

- 1 multimeter in HC20 hard case
- 1 pair of safety measurement cables with 4 mm test probes, 1000 V CAT III, 600 V CAT IV (KS17-2)
- 2 batteries, 1.5 V, type AA
- 1 DAkkS calibration certificate
- 1 protective rubber holster
- 1 condensed operating instructions\*, English/German
- Detailed operating instructions are available for download on the Internet at www.gossenmetrawatt.com

#### Voluntary Manufacturer's Guarantee

36 months for materials and workmanship

1 to 3 years for calibration (depending upon application)

<sup>2) 16</sup> Mbit = 2048 kByte = 61,600 measured values, sampling rate adjustable from 0.1 seconds to 9 hours

<sup>3)</sup> IP65 is available in model METRAHIT OUTDOOR (M2400). More informationen about this model is provided in our Measuring and Test Technology catalog and at our website www.gossenmetrawatt.com.

#### **Specifications**

Meas.			n at Upper	Input Im	nedance		er Reference Conditions for		Overload	Capacity <sup>2)</sup>
Function	Measuring Range	Range Limit		input iiii		±( % rdg. + d)	±( % rdg. + d)	±( % rdg. + d)		
T direction		59 999	5999	===	~/≅		<b>~</b> ¹)	≂1)	Value	Time
	600 mV	10 μV	100 μV	≥9 MΩ	≥9 MΩ // < 50 pF	0.09 + 5 with ZERO *)	0.5 + 30	1 + 30	1000 V	
	6 V	100 μV	1 mV	≥9 MΩ	$\geq$ 9 M $\Omega$ // < 50 pF	0.05 + 5	0.5 + 9	1 + 30	DC	
V	60 V	1 mV	10 mV	≥9 MΩ	≥9 MΩ // < 50 pF	0.05 + 5	0.5 + 9	1 + 30	AC	continous
-	600 V	10 mV	100 mV	≥9 MΩ	≥9 MΩ // < 50 pF	0.05 + 5	0.5 + 9	1 + 30	RMS	
	1000 V	100 mV	1 V	≥9 MΩ	$\geq 9 \text{ M}\Omega \text{ //} < 50 \text{ pF}$	0.09 + 5	0.5 + 9	1 + 30	Sine	
	1000 V	100 1110	1 V		reference voltage	0.03 + 3		1 + 30		
	6001/2			UREF =	0.775 V		Intrinsic Uncertainty			
	600 mV~			-48 dB		_			1000 V	
	6 V~			–28 dB					DC	
dB	60 V~		0.01 dB		. +38 dB		0.1 dB (U > 10 % MB)		AC RMS	continous
	600 V~				+58 dB					
	1000 V~			+22 dB	+63 dB				Sine	
				Voltage drop, approx	. at upper range limit		<b>~</b> ¹)	≂1)		
	600 μΑ	10 nA	100 nA	150 mV	150 mV	0.5 + 5 with ZERO *)	1 + 10	1.5 + 30		
	<b>6</b> mA	100 nA	1 μΑ	200 mV	200 mV	0.5 + 5	1 + 10	1.5 + 30	1	
	60 mA	1 μΑ	10 μΑ	200 mV	200 mV	0,1 + 5 with ZERO *)	1 + 10	1.5 + 30	0.7 A	continous
A	600 mA	10 μΑ	100 μΑ	300 mV	300 mV	0.2 + 5	1 + 10	1.5 + 30	-	
	~								40.4	= 1 10)
	A 9 esial 9 A	100 μΑ	1 mA	300 mV	300 mV	0.9 + 10	1 + 10	1.5 + 30	10 A: ≤	5 min <sup>10)</sup>
	<b>基本</b> 量 10 A	1 mA	10 mA	600 mV	600 mV	0.9 + 10	1.5 + 10	1.5 + 30	16 A: ≤	30 s <sup>10)</sup>
	Factor 1:1/10/100/1000	Input		Input im	pedance					
	0.06/0.6/6/60 A	60	) mA			0 "			Measur	ing input
A>C	0.6/6/60/600 A	600		Current mea	asuring input	Specif	fication see current range	es A~		ontinous
~~	6/60/600/6 000 A	6		(A soc	ket 🖁 )	plue ola	mp current transforn	oor orror		5 min
	0/00/000/0 000 A		) A			pius cia	mp current transion	lei eiioi		
	0.6/6/60/600 A	600 mV 6 V		Voltage meas	urement input	0				ing input
A>C	6/60/600/6000 A			(V socket ) Ri	=1 MΩ/9 MΩ	Specification	see voltage measuring r	anges v~ "		V RMS
				` ′		1/ 0/	I		max.	. 10 s
	600 Ω	10 mΩ	100 mΩ	< 1.4 V	Meas. curr. @ range limit approx. 250 μA	,	lg. + d) with ZERO*)			
							,			
	6 kΩ	100 mΩ	1 Ω	< 1.4 V	approx. 65 μA		with ZERO*)		400014	
Ω	60 kΩ	1 Ω	10 Ω	< 1.4 V	approx. 7.5 μA	0.1 + 5			1000 V	
""	600 kΩ	10 Ω	100 Ω	< 1.4 V	approx. 0.75 μA	0.2 + 5			DC	may 10 a
	6 MΩ	100 Ω	1 kΩ	< 1.4 V	approx. 0.1 μA	0.5 + 5			AC RMS	max. 10 s
	60 MΩ	1 kΩ	10 kΩ	< 1.4 V	approx. 30 nA	5 + 10			Sine	
<b>d</b> )	600 Ω	_	0.1 Ω	approx. 9 V	approx. 1 mA const.	3 + 5			OILIC	
-	6.0 V <sup>3)</sup>		1 mV	approx. 9 V	approx. 1 mA const.	0.5 + 3			1	
->-	0.0 V '	_	I IIIV				L			
	20 5		40 5	Discharge resist.	U <sub>0 max</sub>		lg. + d)			
F	60 nF	_	10 pF	10 MΩ	0.7 V		with ZERO *)			
PM XTRA	600 nF	_	100 pF	1 MΩ	0.7 V	1 + 6 4)			1000 V	
EXTRA	6 μF	_	1 nF	100 kΩ	0.7 V	1 + 6 4)			DC	
	60 μF	_	10 nF	12 kΩ	0.7 V	1 + 6 4)			AC	max. 10 s
PM TUNE	•								RMS	
PM TECH	600 μF	_	100 nF	3 kΩ	0.7 V	5 + 6 <sup>4)</sup>			Sine	
Етесн	·									
					f <sub>min</sub> <sup>5)</sup>	±( % rc	lg. + d)			
Hz (V)	600.00 Hz	0.01 Hz	0.1 Hz						Hz (V) <sup>6)</sup> ;	
Hz (A)	6.0000 kHz	0.1 Hz	1 Hz		1 Hz				Hz(A <b>&gt;</b> C) <sup>6)</sup>	
	CO 000 141-		10 11-		I IIZ	0.05 + 5	5 8)			max. 10 s
Hz (A <b>&gt;</b> ∞)	60.000 kHz	1 Hz	10 Hz			0.00 1			1000 V	
Hz (V)	300.00 kHz	10 Hz	100 Hz		10 Hz				Hz (A): <sup>7)</sup>	
						1	I		112 (A). /	
MHz										
PM XTRA	600 Hz 1 MHz	0.01	0.1		1 100 Hz	0.05 . 5	. 01/ 51/			
EXTRA	600 HZ 1 IVIHZ	100 Hz	1 kHz		1 100 HZ	0.05 + 5	> 2 V 5 V			
PM TUNE	2.0 00.0/		0.01.0/	1511- 1111-		0.1 D . E d	. 0V EV		1000 V	max. 10 s
%	2.0 98 %	_	0.01 %	15 Hz 1 kHz		0.1 R + 5 d	> 2 V 5 V			
PM XTRA	5.0 95 %	_	0.01 %	1 kHz 10 kHz		0.2 R per kHz	> 2 V 5 V			
EXTRA	2.2 00 /0					+ 5 d				
	10 90 %	_	0.01 %	10 kHz 50 kHz		0.5 R per kHz	> 2 V 5 V			
PM TUNE	10 90 /0		0.01 /0	TUNIE JUNIE		+ 5 d				
						±( % rc	lg. + d)			
	Pt 100 - 200.0					00.40	= 9)			
	Pt 100 - 200.0 +850.0 °C					0.3 + 15	5 9)		1000 V	
or/oe	+850.0 °C	01 00							DC/AC	may 10 a
°C/°F	Pt 100	0.1 °C				0.3 + 15 0.3 + 15			DC/AC RMS	max. 10 s
°C/°F	+850.0 °C	0.1 °C					5 9)		DC/AC	max. 10 s

Specified accuracy is valid as of 3% of the measuring range.
With short-circuited test probes: residual value of 1 to 30 d at zero point due to the TRMS converter (exception: mV AC range, 60 counts). See frequency influence on page 4.

2) At 0 °C ... + 40 °C

At 0 °C ... + 40 °C
 Displays up to max. 6.0 V, "OL" in excess of 6.0 V.
 Applies to measurements at film capacitors and battery operated
 Lowest measurable frequency for sinusoidal measuring signals symmetrical to the zero point
 Overload capacity of the voltage measurement input: power limiting: frequency x voltage max. 6 x 10<sup>6</sup> V x Hz for U > 100 V

- Overload capacity of the current measurement input: See current measuring ranges for maximum current values.
- Input sensitivity, sinusoidal signal, 10% to 100% of the measuring range

9) Plus sensor deviation

- 10) Off-time > 30 min and  $T_A \le 40$  °C \*) without ZERO max.  $\pm$  15 digit

d = counts, R = measuring range, rdg. = measured value (reading)

Internal Clock

Time format DD.MM.YYYY hh:mm:ss

Resolution  $0.1 \, s$ 

Accuracy ±1 min. per month

Temperature

50 ppm/K Influence

#### Influencing Quantities and Influence Error

Influencing Quantity	Sphere of Influence	Measured Quantity / Measuring Range 1)	Influence Error (% rdg. + d) / 10 K
		V <del></del>	0.2 + 10
		V ~	0.4 + 10
		600 Ω 6 MΩ	0.5 + 10
	-10 °C +21 °C und +25 °C +40 °C	> 6 MΩ	1 + 10
Temperature		mA/A <del></del>	0.5 + 10
lemperature		mA/A ≅	0.8 + 10
		60 nF 600 μF	1 + 5
		Hz, dB	0.2 + 10
		°C/°F (Pt100/Pt1000)	0.5 + 10
		°C/°F thermocouple K	0.2 + 10

<sup>1)</sup> With zero balancing

Influencing Qty.	Meas. Qty.	/ Meas. Range	Sphere of Influence	Intrinsic Uncertainty <sup>3)</sup> ±(% rdg. + d)  METRA HIT PM XTRA METRAHIT PM TUNE METRAHIT PM TECH METRAHIT EV PRO METRAHIT EXTRA METRAHIT ESPECIAL
			> 15 Hz 45 Hz	3 + 30
	V <sub>AC</sub>	600.00 mV	> 65 Hz 1 kHz	2 + 30
			> 1 kHz 20 kHz	3 + 30
			> 15 Hz 45 Hz	2 + 9
		6.0000 V	> 65 Hz 1 kHz	1 + 9
_		600.00 V <sup>2)</sup>	> 1 kHz 20 kHz <sup>4)</sup>	3 + 9
Frequency			> 20 kHz 100 kHz <sup>4)</sup>	3.5 + 30
			> 15 Hz 45 Hz	2 + 9
		1000.0 V <sup>2)</sup>	> 65 Hz 1 kHz	2 + 9
			> 1 kHz 10 kHz	3 + 30
		600.00 μΑ	> 15 Hz 45 Hz	
	A <sub>AC</sub>	 10.0000 A	>65 Hz 10 kHz	3 + 10

Power limiting: frequency x voltage max.  $6 \times 10^6 \text{ V} \times \text{Hz}$  for U > 100 V

The accuracy specification for frequency response is valid within a display value range of 10% to 100% of the measuring range for both measuring modes with the TRMS converter in the AC and (AC+DC) ranges.

4) METRA HIT PM XTRA / PM TUNE / EXTRA:

frequency response up to 100 kHz, > 50 kHz plus 2.5 %

METRAHIT PM TECH / ETECH: METRAHIT EU PRO / ESPECIAL:

2 00 11 12 pido 210 70
frequency response up to 20 kHz,
frequency response up to 20 kHz

	Influencing Quantity	Sphere of Influence	Measured Quantity/ Measuring Range	Influence Error <sup>5)</sup>
Ι,	Crest factor CF	1 3	٧. ٨.	± 1 % rdg.
ľ	SIEST IACTOR OF	> 3 5	V ~, A ~	± 3 % rdg.

<sup>5)</sup> Except for sinusoidal waveshape

Influencing Quantity	Sphere of Influence	Measured Quantity	Influence Error
	75%		
Relative humidity	3 days	V, A, Ω, F, Hz, dB, °C	1 x intrinsic uncertainty
	instrument off		
Battery voltage	2.0 to 3.6 V	V, A, Ω, F, Hz, dB, °C	Included in intrinsic uncertainty

Influencing Quantity	Sphere of Influence	Measured Quantity / Measuring Range	Damping
	Interference quantity max. 1000 V ~	V <del></del>	> 120 dB
Common Mode Interference		6 V $\sim$ , 60 V $\sim$	> 80 dB
Voltage	Interference quantity max. 1000 V ~ 50 Hz 60 Hz, sine	600 V ∼	> 70 dB
-		1000 V ∼	> 60 dB
Series Mode Interference	Interference quantity: V $\sim$ , respective nominal value of the measuring range, max. 1000 V $\sim$ , 50 Hz 60 Hz, sine	V <del></del>	> 50 dB
Voltage	Interference quantity max. 1000 V —	V ~	> 110 dB

#### **Reference Conditions**

Ambient temperature +23 °C ±2 K Relative humidity 40 ... 75% Measured qty. frequency 45 ... 65 Hz Measured qty. waveform Sine Battery voltage 3 V ±0.1 V

#### **Response Time** (after manual range selection)

Measured Quantity / Measuring Range	Response Time Digital Display	Measured Quantity waveshape
V == , V ∼, dB AV == , A ∼	1.5 s	From 0 to 80 % of upper range limit value
600 Ω 6 MΩ	2 s	
60 MΩ	5 s	
Continuity	< 50 ms	From ∞ to 50 % of upper range limit value
°C (Pt 100)	Max. 3 s	or apper range innit raids
→-	1.5 s	
60 nF 600 μF	Max. 2 s	From 0 to 50 %
>10 Hz	1.5 s	of upper range limit value

#### **Data Interface**

Type

Data transmission Protocol

Optical via infrared light through the housing Serial, bidirectional (not IrDa compatible) Device specific

Baud rate 38,400 baud

**Functions** 

- Select/query measuring functions and parameters

- Query momentary measurement data

- Read out stored measurement data

The USB X-TRA plug-in interface adapter (see accessories) is used for connection to the PC's USB port.

#### **Internal Measured Value Storage** (METRA HIT PM XTRA / PM TUNE / EXTRA only)

Memory capacity

16 MBit (2 MByte) for approx. 61,000 measured values with date and time stamp

**Power Supply** 

Battery 2 ea. 1.5 V mignon cell (2 ea. size AA),

alkaline manganese per IEC LR6 (2 ea. 1.2 V NiMH rechargeable battery

also possible)

Service life with alkaline manganese (2600 mAh):

approx. 200 hours

Battery test Battery capacity display with battery

symbol in 4 segments: ......

Querying of momentary battery voltage via

menu function.

Power OFF function Multimeter is switched off automatically:

If battery voltage drops to below prox. 2.0 V
 If none of the keys or the rotary switch are activated for an adjustable duration of 10 to 59 minutes, and the multimeter.

of 10 to 59 minutes, and the multimeter is not in the continuous operation mode

Power pack socket (METRA HIT PM XTRA / PM TUNE / EXTRA only) If the NA X-TRA power pack has been plugged into the instrument, the batteries are disconnected au-

tomatically.

Rechargeable batteries can only be

recharged externally.

#### **Display**

LCD panel (65 mm x 36 mm) with analog and digital display including unit of measure, type of current and various special functions

#### **Background illumination**

Background illumination is switched off approximately 1 minute after it has been activated.

Analog

Display LCD scale with bar graph or pointer, depend-

ing on the selected parameter setting

Scaling With 4 division lines each, 1 bar/pointer cor-

responds to 500 counts at the digital display

Polarity display With automatic switching Overflow display With the ▶ symbol

Measuring rate 40 measurements per second and display

refresh

Digital

Display / char. height 7-segment characters / 15 mm

Resolution 59,999 counts

Overflow display "OL" is displayed for  $\geq$  60,000 counts

Polarity display "-" (minus sign) is displayed if plus pola is connected to "I

if plus pole is connected to "⊥"

Measuring rate 10 or 40 measurements per second with

the Min-Max function except for the capacitance, frequency and duty cycle

measuring functions

Refresh rate all instruments except for **METRAHIT PM TUNE**:

2 times per sec., every 500 ms (Parameter "noFil" is off by default)

METRAHIT PM TUNE: 5 x/s

(Parameter "noFiL" is on by default)

### Acoustic Signals

For voltage Intermittent signal at above 1000 V
For current Intermittent signal at above 10 A
Continuous signal at above 16 A

# Fuse for METRA HIT PM XTRA / PM TUNE / EXTRA, METRA HIT PM TECH / ETECH

Fuse FF (UR) 10 A/1000 V AC/DC;

10 mm x 38 mm,

Switching capacity: 30 kA at 1000 V AC/DC, protects the current measurement input in the 600  $\mu$ A through 10 A ranges

#### **Electrical Safety**

Per IEC 61010-1:2010/VDE 0411-1:2011

#### METRA HIT PM XTRA / PM TUNE / Extra, METRAHIT PM TECH / ETECH

Safety class II

Measuring category III IV
Operating voltage 1000 V 600 V

Pollution degree 2
Test voltage 6.7 kV~

METRAHIT EU PRO / METRAHIT ESPECIAL "for Current Transformers"

Special device for measurements at current transformers without

fuse in the electrical circuit

Safety class II

Measuring category 600 V CAT II

Pollution degree 2
Test voltage 3.5 kV~

#### **Electromagnetic Compatibility (EMC)**

Interference emission EN 61326-1: 2013, class B

Interference immunity EN 61326-1: 2013

EN 61326-2-1: 2013

#### **Ambient Conditions**

Accuracy range 0 °C ... +40 °C Operating temp. range  $T_A$  -10 °C ... +50 °C

Storage temp. range -25 °C ... +70 °C (without batteries) Relative humidity 40 ... 75%, no condensation allowed

Elevation Up to 2000 m

Deployment Indoors, except within specified ambi-

ent conditions

#### **Mechanical Design**

Housing Impact resistant plastic (ABS)

Dimensions 200 x 87 x 45 mm

(without protective rubber holster) Approx. 0.35 kg with batteries

Weight Approx. 0.35 kg with batteries
Protection Housing: IP 52 (pressure equalization by

means of the housing)

Table excerpt regarding significance of the

IP code

IP XY (1 <sup>st</sup> digit X)	Protection against pene- tration of solid particles	IP XY (2 <sup>nd</sup> digit Y)	Protection against penetration by water
5	Dust protected	2	Dripping (15° inclination)

#### Accessories for Operation at a PC

#### Interface Adapter for USB Connection

The following functions can be executed with the USB X-TRA bidirectional interface adapter:

- Configure the METRAHIT multimeter from a PC.
- Transmit live measurement data to the PC.
- Read out data from memory at the METRA HIT PM XTRA / PM TUNE / EXTRA.

The adapter does not require a separate power supply. Its baud rate is 38,400 baud.

A CD ROM is included which contains current drivers for Windows operating systems.





Application example

### METRAwi<sup>®</sup>10/METRA*Hit*<sup>®</sup> Software

METRAwin<sup>®</sup> 10/METRAHit <sup>®</sup> PC software is a multilingual, measurement data logging program for recording, visualizing and documenting measured values of multimeters of the METRAHIT Advanced and Professional as well as the METRAHIT A and E Series.

Communication between the PC and the measuring instrument(s) is established via available interface adapters.

Depending upon device type, one or several of the following operating modes are possible:

#### Device Configuration

Remote configuration and querying of device-specific functions and parameters, for example measuring function, measuring range and memory parameters. Frequently used device settings can be saved to configuration files for easy recall.

#### Online Recording of Measurement Data

Read-in, display and recording of momentarily measured data from the interconnected device.


- Number of
  - measuring channels up to 10
- Start recording manual, triggered by measured value,
  - time triggered
- Recording mode > time controlled
  - with sampling interval of 0.05 s\* ...
  - 1 s ... 60 min
  - > manually controlled
  - > measured value controlled in event of exceeded limit/delta value
- Recording duration max. 10 million intervals
- Depending upon device type, measuring function, number of measuring channels and communication (e.g. via modem), sample intervals of less than 1 s cannot be used.

#### Reading Out and Visualizing Stored Data


If supported by the device: read-in and display of offline data recorded to device memory.

For purposes of analysis, data recorded online or read in from the device's memory can be displayed in various formats:

### Y(t)-recorder display for up to 6 channels




# XY-recorder display for up to 4 channels



# Multimeter-display for up to 4 channels



## Tabular display for up to 10 channels



#### System Requirements

METRAwin 10 (as of version 6.20) can be run on PCs, notebooks and tablets with Microsoft Windows  $^{(\!n\!)}$  Vista, 7, 8 or 10.

Article Number

#### **Order Information**

Designation

METRA HIT PM XTRA, METRAHIT PM TUNE, METRAHIT PM TECH, METRAHIT EU PRO, METRAHIT EXTRA, METRAHIT ETECH, METRAHIT ESPECIAL multimeters 60, 000 counts TRMS multimeter with direct, alternating and pulsating voltage measurement (TRMS values), direct, alternating and pulsating current measurement (TRMS values), frequency measurement, resistance measurement, continuity test, diode measurement and temperature measurement with type K thermocouples LCD with 15 mm characters, analog bar graph and background illumination Measuring categories: 600 WCAT IV, 1000 WCAT III Current measurement via clamp sensors with voltage output and adjustable clamp factor All multimeters include the KS17-2 measurement cable set, two mignon batteries, condensed operating instructions, CD ROM, DAkkS calibration certificate, hard case HC20					
Same as above but with additional broad range capacitance measurement, precision temperature measurement with Pt100 or Pt1000 platinum resistance thermometers, frequency and duty cycle measurement, clamp current transforme with current output, with power pack socket and IR interface, 2 MB data memory, protective rubber holster	ır	M250A			
Same as <b>METRA HIT PM XTRA</b> , with faster display refresh activated	METRAHIT PM TUNE	M250T			
Same as above but with additional broad range capacitance measurement, with additional current measurement via clam current transformer with current output		M253A			
Same as above Special device without integrated fuse for use in current transformer circuits	METRAHIT EU PRO	M252A			
Accessories for operation at a PC					
IR-USB bidirectional interface adapter	USB X-TRA	Z216C			
METRAwin 10 software	METRAwin 10	GTZ3240000R0001			
Accessories for temperature measurem (METRA HIT PM XTRA / PM TUNE / EXTR	ent with resistance ther A only)	mometer			
Pt100 temperature sensor for surface an immersion measurement, -40 to +600 °C	Z3409	GTZ3409000R0001			
Pt1000 temperature sensor for measurement in gases and liquids, -50 to +220 °C	TF220	Z102A			
Pt100 oven sensor, -50 to +550 °C	TF550	GTZ3408000R0001			
Replacement fuse (METRA HIT PM XTRA / PM TUNE / EXT	RA and METRAHIT PM T	ECH / ETECH only)			
Fuses (pack of 10)	FF (UR) 10 A / 1000 V AC/DC	Z109L			
Power pack (for METRA HIT PM XTRA PM TUNE / Extra only)	/ NA X-TRA	Z218G			
Protective rubber holster and carrying stra	GH X-TRA	Z104C			

Type

#### **Transport Accessories**

#### HitBag Cordura Belt Pouch

For METRA HIT | multimeters (with/without protective rubber holster) and METRAport



#### HC30 Hard Case

For two multimeters (with/without protective rubber holster) and accessories



F836 Ever-Ready Case

For multimeter and accessories



F829 Carrying Pouch
For multimeters (with/without
protective rubber holster)
and accessories



Designation	Туре	Article Number
Imitation leather without protective rubber holster for <b>METRA HIT</b> and METRAmax	F829	GTZ3301000R0003
Cordura belt pouch for METRA HIT multimeters and METRAport	HitBag	Z115A
Imitation leather ever-ready case with cable compartment	F836	GTZ3302000R0001
Hard case for one <b>METRA HIT</b> and accessories	HC20	Z113A
Hard case for two METRA HIT and accessories	HC30	Z113A

For additional information regarding accessories please refer to:

- our Measuring and Test Technology catalog.
- our website www.gossenmetrawatt.com

	sensors and transformers are equipped		, ,			-		
Туре	Designation	Measuring Range	Meas. Category	Max. Wire Diameter	Transformation Factor	Frequency Range	Intrinsic Uncertainty ±(% rdg. +)	Article Number
DC/AC Curi	rent Sensors with Voltage Output				:		-	
CP30	DC/AC current clamp sensor, with battery mode (30 h)	5 mA to 30 A (DC / AC pk)	300 V / CAT III	25 mm	100 mV/A	DC20 kHz (-3 dB)	1 % +2 mA	Z201B
CP330	DC/AC current clamp sensor, with 2 measuring ranges, battery mode (50 h)	Range: 0.5 30 A Range: 5 300 A (DC / AC rms)	300 V / CAT III	25 mm	10 mV/A; 1 mV/A	DC20 kHz (-3 dB)	1 % + 50 mA 1 % + 100 mA	Z202B
CP1100	DC/AC current clamp sensor, with 2 measuring ranges, battery mode (50 h)	Range: 0.5 100 A Range: 5 1000 A (DC / AC rms)	300 V / CAT III	32 mm	10 mV/A; 1 mV/A	DC20 kHz (-1 dB)	1 % + 100 mA 1 % + 500 mA	Z203B
CP1800	DC/AC current clamp sensor, with 2 measuring ranges, battery mode (50 h)	Range: 0.5 125 A Range: 5 1250 A (DC / AC rms)	300 V / CAT III	32 mm	10 mV/A, 1 mV/A	DC 20 kHz (-1 dB)	1% + 100 mA 1% + 500 mA	Z204A
AC Current	Sensors with Voltage Output							
WZ12B	AC clamp current sensor	10 mA~ 100 A~	300 V CAT III	15 mm	100 mV/A	<u>45 65</u> 500 Hz	1.5% +0.1 mA	Z219B
WZ12C	AC clamp current sensor, with 2 measuring ranges	1 mA~ 15 A~, 1 150 A~	300 V CAT III	15 mm	1 mV/mA, 1 mV/A	45 65 400 Hz	3% + 0.15 mA, 2% + 0.1 A	Z219C
WZ11B	AC clamp current sensor, with 2 measuring ranges	0.5 20 A~, 5 200 A~	600 V CAT III	20 mm	100 mV/A, 10 mV/A	30 <u>48 65</u> 500 Hz	1 3%	Z208B
Z3512A	AC clamp current sensor, with 4 measuring ranges	1 mA 1/10/100/1000 A~	600 V CAT III	52 mm	1 V/A, 100 mV/A, 10 mV/A, 1 mV/A	10 <u>48 65</u> 3 kHz	0.5 3%, 0.2 1%	Z225A
METRA- FLEX3000	Flexible AC current sensor with 3 measuring ranges, battery mode (2000 h)	0,5 30 A, 0,5 300 A, 5 3000 A	1000 V CAT III 600 V CAT IV	176 mm	100 mV/A, 10 mV/A, 1 mV/A	10 Hz 20 kHz	1% + 0.1 A 1% + 0.1 A 1% + 1 A	Z207E
METRA- FLEX300M	Flexible AC miniature current sensor with 3 measuring ranges, battery mode (150 h)	1 3 A, 1 30 A, 5 300 A	1000 V CAT III 600 V CAT IV	50 mm	1 V/A, 100 mV/A, 10 mV/A	20 Hz 100 kHz	1% + 0.2 A 1% + 0.2 A 1% + 1 A	Z207M
AC Current	Transformer with Current Output							
WZ12A	AC clamp current transformer	15 180 A~	300 V CAT III	15 mm	1 mA/A	45 65 400 Hz	3%	Z219A
WZ12D	AC clamp current transformer	30 mA 150 A~	300 V CAT III	15 mm	1 mA/A	<u>45 65</u> 500 Hz	2.5% + 0.1 mA	Z219D
WZ11A	AC clamp current transformer	1 200 A~	600 V CAT III	20 mm	1 mA/A	48 65 400 Hz	1 3%	Z208A
Z3511	AC clamp current transformer	4 500 A~	600 V CAT III	30 x 63 mm	1 mA/A	48 65 1 kHz	3% + 0.4 A	GTZ35110 0R0001
Z3512	AC clamp current transformer	0.5 1000 A~	600 V CAT III	52 mm	1 mA/A	30 <u>48 65</u> 5 kHz	0.5% 0.7%	GTZ35120 0R0001

© Gossen Metrawatt GmbH

Edited in Germany • Subject to change without notice / Errors excepted • A PDF version is available on the Internet

All trademarks, registered trademarks, logos, product names and company names are the property of their respective owners.



Gossen Metrawatt GmbH Südwestpark 15 90449 Nürnberg • Germany Phone +49 911 8602-111 Fax +49 911 8602-777

E-Mail info@gossenmetrawatt.com

www.gossenmetrawatt.com